

Acer

WLAN 11b USB Adapter

Quick Start Guide

Version 1.0

Drivers and Utility Installation

Drivers and Utility Installation

This section describes the procedures for installing the Acer WLAN 11b USB Adapter.

Before You Start

Before installation, please check your system in advance and ensure it meets the minimum requirements as described below.


- Processor: Intel Celeron / Pentium II / Pentium III / Pentium IV; AMD Duron / Athlon
- Operating System: Microsoft Windows 98SE / ME / 2000 / XP
- System memory: 32MB at least
- Hard Drive Free Space: 5MB

Note: To prevent potential problems during installation, please use the auto-run installation tool on the CD to finish the driver installation before you plug the Acer WLAN 11b USB Adapter into the computer.


To use the Acer WLAN 11b USB Adapter with a computing device, the device must be equipped with an available USB port. All drivers and supporting software for the Acer WLAN 11b USB Adapter must be installed and configured.

The installation & driver CD will auto run installation program. For example, below shows the installing under Windows XP.


1. Insert the installation & driver CD to your CD-ROM




2. Click "Next" to continue.



3. Click “Next” to install at the designated folder. Or, click “Browse” to select different folder.




4. Start copying files until it finish the installation.




5. Insert the Acer WLAN 11b USB Adapter into the USB of your PC. When Windows is ready to configure the new hardware, it opens the “Found New Hardware Wizard” dialog box as shown below. Select “Install the software automatically (Recommended)” and click “Next” to continue.



6. The Wizard is searching the driver.



7. Start copying the driver



8. Click "Finish" to complete the Setup.

