
Control v1

(Home Edition)

User Manual

Home Automation Software for
Microsoft Windows[®] XP
Media Center Edition 2005

Table of Contents

TABLE OF CONTENTS	2
INTRODUCTION.....	7
SYSTEM REQUIREMENTS	8
SOFTWARE REQUIREMENTS	8
<i>mControl (Automation) Service</i>	<i>8</i>
<i>mControl (User Interface) Client.....</i>	<i>8</i>
MEDIA CENTER INTERFACE.....	8
<i>Screen Settings.....</i>	<i>8</i>
<i>Supported Media Center Extenders.....</i>	<i>8</i>
SUPPORTED HARDWARE.....	9
<i>Security Cameras.....</i>	<i>9</i>
<i>Security Systems.....</i>	<i>10</i>
<i>HVAC Systems</i>	<i>11</i>
<i>Irrigation Controllers.....</i>	<i>11</i>
<i>IR Support.....</i>	<i>12</i>
<i>Voice Recognition Support.....</i>	<i>12</i>
INSTEON Protocol.....	13
INSTEON Adapters.....	13
INSTEON Devices	15
Two-Way INSTEON Communication.....	16
<i>Link Databases.....</i>	<i>16</i>
<i>Updating Device Status</i>	<i>17</i>
<i>Macro Triggering and Real-time Status Changes from SwitchLinc Paddle Presses</i>	<i>17</i>
Setting Preset On and Ramp Rates.....	18
X10 to INSTEON Translator	18
Z-Wave Protocol.....	19
Z-Wave Adapters.....	19
<i>Real-time Information Display</i>	<i>20</i>
Z-Wave Devices	21
Z-Wave Adapter Utility.....	22
<i>Connection Options</i>	<i>23</i>
<i>Controller Options</i>	<i>24</i>
<i>Device Options</i>	<i>25</i>
<i>mControl Automation Service Options</i>	<i>26</i>
<i>Z-Wave Adapter Information.....</i>	<i>26</i>
Adding Z-Wave Devices to mControl.....	27
Removing Z-Wave Devices from mControl	28
X10 Protocol.....	29
X10 Adapters	29
X10 Devices	30
Leviton X10 Devices	31
Limitations and Recommendations.....	32
MCONTROL INSTALLATION.....	33
STEP 1 - INSTALL MCONTROL SOFTWARE.....	33
<i>Upgrading mControl.....</i>	<i>33</i>
<i>Download the Latest Version of mControl.....</i>	<i>33</i>
<i>Extract and Install mControl</i>	<i>34</i>
STEP 2 - START MCONTROL SOFTWARE	39

Starting mControl using an Internet Explorer Browser.....	39
Starting mControl within Media Center.....	40
STEP 3 – ACTIVATING MCONTROL	41
mControl Trial Version	41
Replace the mControl Trial License with a Purchased License	41
Activating the mControl License.....	42
Using mControl with a Dial-up Internet Connection	44
USING MCONTROL SOFTWARE	45
MCONTROL COMPONENTS	45
mControl (User Interface) Client.....	45
mControl (Automation) Service	45
mControl Service Manager	45
mControl Client and Service Interaction.....	46
MCONTROL USER INTERFACE	47
Zone View Screen	47
Zones Area	47
Access to mControl Settings	48
Devices Area	48
Real-time Display of Device Status	49
Switches, Lamp and Appliance Devices.....	50
HVAC (Thermometer) Devices	51
Irrigation Devices	51
Security System Devices.....	52
Camera Devices	52
Macro Devices	53
Settings Screen.....	54
Settings Options	54
Configuration Options	54
mControl Information.....	55
Configuration Screen	56
Configuration Options	56
Configuration Settings (Main).....	57
Configuration Settings (Location).....	58
Manage Zones Screen	59
Manage Zone Options	59
Zone Configuration.....	60
Add Zone Screen.....	61
Add Zone Options.....	61
Zone Name.....	61
Edit Zone Screen.....	62
Edit Zone Options	62
Zone Configuration.....	63
Edit Device Screen.....	64
Edit Device Options.....	64
Device Configuration Menu	65
Device Settings (Main)	66
Device Settings (Advanced).....	69
INSTEON Ramp Rates and Preset On Options.....	70
Z-Wave Preset On Option	70
Automation Screen.....	71
Automation Options.....	71
Macro List	72
Add Macro Screen	73
Add Macro Options	73
Macro Details Screen.....	74
Macro Details Options.....	74
Macro Triggers List	75

Macro Actions List	76
Edit Macro Screen.....	77
Macro Triggers.....	78
Device Triggers.....	79
IR Event Triggers.....	81
MCE Event Triggers.....	82
One Time Triggers.....	84
Time of Day Triggers	85
Sunrise/Sunset Triggers.....	86
Macro Actions.....	87
Device Actions.....	88
Delay Actions.....	89
IR Actions.....	90
Macro Actions.....	91
Send Mail Actions.....	92
Run Application Actions	93
Camera Screen	94
Automation Options.....	94
Camera List	94
Add Camera and Edit Camera Screens.....	95
Edit Camera Options.....	95
Camera Settings	96
Camera Media Screen.....	97
Edit Camera Options.....	97
Camera Media List.....	97
IR Control Screen	98
IR Control Options.....	98
IR Control Configuration.....	98
Adapters Ports	99
Adapter Ports.....	99
IR Commands	100
IR Command Options.....	100
IR Commands	100
ADVANCED MCONTROL FUNCTIONALITY	101
Using Macros.....	101
Device Triggered Macros.....	101
Triggering Macros Using INSTEON SwitchLinc or KeypadLinc Buttons.....	104
Time Triggered Macros.....	105
MCE Event Triggered Macros.....	108
Install and configure the MCE Add-in Utility.....	108
Create the Macro to Utilize MCE Events	110
Using External Programs within Macro Actions	112
Enable External Program Action Functionality.....	112
Enable Interactive Applications (GUI Apps).....	112
Example External Application Action.....	113
Using Security Systems.....	115
Supported Security Systems	115
Using Elk Security Systems	115
Using Digital System Control (DSC) PowerSeries Security Systems	117
Using Honeywell ADEMCO VISTA Security Systems	119
Understanding Security Systems Status.....	121
Changing Security Systems Settings.....	122
Security View Screen Overview.....	122
Security View Main Tab.....	123
Security Zones Tab.....	124
Triggering Macros using Security System Events	125
Using Irrigation Controllers	126
Irrigation Controllers.....	126
EZ Rain V1 Irrigation Controllers.....	126

Add an EZRain Irrigation Controller to mControl	126
Changing or Viewing EZRain Settings	129
Main Tab	130
Manual Tab	131
Program Tab	132
Using Thermostats	133
Using HAI Thermostats	133
Using RCS Thermostats	135
Using RCS TXB16 Thermostats	135
Using RCS TZ16 Thermostats	137
Understanding Thermostat Status	138
Changing Thermostat Settings	139
Adjusting HVAC Settings in Macros	140
Using Cameras	141
Using Axis Cameras	141
Using Panasonic Cameras	145
Using D-Link Cameras	149
Adding a Custom Camera	153
Using Advanced Camera Functionality from the Camera View page	155
Camera View Options	155
Pan-Tilt-Zoom Options	155
Using Camera Devices within Macros	156
Triggering Macros based on Camera Motion Detection	156
Recording Videos as a Macro Action	160
Taking Snapshots as a Macro Action	162
Viewing Recorded Videos and Snapshots within Windows Media Center	163
Using IR Commands	165
Configuring Global Caché for Use with mControl	165
Configuring USB UIRT for Use with mControl	168
Entering and Testing IR Commands	170
Adding IR Commands (using CCF Format)	170
Learning IR Commands	171
Testing IR Commands	172
Sending IR commands within mControl Macros Actions	173
Using IR commands as mControl Macros Triggers	174
IR Commands and Windows XP Media Center Edition 2005	174
Adding Voice Control	175
Basic Voice Control Operation	175
Extending Voice Control	177
Configuring mControl Clients	178
Using mControl from a remote PC using Internet Explorer	178
Adding mControl to a remote Windows XP Media Center Edition PC	178
Adding mControl to the Start Menu of a Windows XP Media Center Edition PC	179
Adding mControl to the More Programs Menu of a Windows XP Media Center Edition PC	180
Using mControl from a Windows Mobile Device	181
Adding mControl to SnapStream's Beyond Media	182
Add a mControl Entry Point to the Beyond Media Menu	182
Add a mControl icon to the mControl Menu Entry	183
Configuring the mControl User Interface	184
Adding Custom Device Images	184
Adding Custom Options	185
Adding Custom Style Sheets	187
User Interface Platforms	187
mControl Images	188
Style Sheets	188
JavaScript Variables	194
XML Variables	196
MCONTROL EDITOR	209
STARTING THE MCONTROL EDITOR	209

MCONTROL EDITOR MENU	210
<i>File options</i>	210
EDITING ZONES	210
EDITING DEVICES	211
VERSION HISTORY	212
v1.70 – RELEASED JANUARY 2007	212
v1.60 – RELEASED SEPTEMBER 2006	213
v1.50 – RELEASED JUNE 2006	214
v1.40 – RELEASED MARCH 2006	215
v1.31 – RELEASED DECEMBER 2005	216
v1.30 – RELEASED NOVEMBER 2005	216
v1.30 – RELEASED NOVEMBER 2005 (CONTINUED)	217
v1.20 – RELEASED SEPTEMBER 2005	218
v1.11 – RELEASED ON AUGUST 3, 2005	218
v1.10 – RELEASED ON JULY 21, 2005	219
v1.00 (RELEASE CANDIDATE 1) – RELEASED ON JUNE 13, 2005	220
KNOWN ISSUES	221
ERROR MANAGEMENT	222
FREQUENTLY ASKED QUESTIONS (FAQS)	223
INSTALLATION AND START-UP	223
X10 AUTOMATION	224
Z-WAVE AUTOMATION	224
INSTEON AUTOMATION	224
ELK SECURITY	225
HVAC	225
SUPPORT	226
LOG FILES	226
CONTACT US	226

Introduction

This purpose of this document is to provide installation instructions for mControl home automation software from Embedded Automation (<http://www.embeddedautomation.com>).

mControl software allows you to control your home from the comfort of your couch or remotely from any internet access point.

System Requirements

Software Requirements

mControl has two main components. By default, they are installed on the same machine.

mControl (Automation) Service

- Operating System
 - Windows 2000
 - Windows XP Home Edition
 - Windows XP Professional
 - Windows XP Media Centre Edition 2005,
- Microsoft.NET framework version 1.1 (or higher)
 - To download visit: <http://msdn.microsoft.com/netframework/downloads/default.aspx>
- Microsoft MDAC version 2.6 (or higher)
 - To download visit: <http://msdn.microsoft.com/> and search for “MDAC”

mControl (User Interface) Client

- Windows XP Media Centre Edition (MCE) 2005 (including Roll-up 2)
- Internet Explorer 6.0 (or higher)
- Ultra-mobile PC (UMPC) Internet Explorer

Media Center Interface

Screen Settings

- Minimum 1024 x 768 screen setting

Supported Media Center Extenders

- Xbox 360 (Media Center Extender)
- Xbox Media Center Extender
- HP x5400 Media Center Extender
- Linksys Media Center Extender (Model WMCE54G)


Supported Hardware

mControl supports a variety of automation systems. The following section summarizes the list of automation systems supported.

Security Cameras


Support for Axis Internet cameras, including:

- Axis models: 206, 206M, 206W, 207, 207W, 210, 210A, 211, 211A, 212PTZ, 213PTZ, 214PTZ, 221 and 225FD

	<p>Embedded Automation is proud to support Axis Communication products as part of mControl.</p> <p>For more information on Axis Communication, visit http://www.axis.com/</p> <p>Image Courtesy of Axis Communication</p>
---	---


Support for Panasonic Internet cameras, including:

- Panasonic models: BB-HCM331

	<p>Embedded Automation is proud to support Panasonic products as part of mControl.</p> <p>For more information on Panasonic, visit http://www.panasonic.com/business/security/network_cameras.asp</p> <p>Image Courtesy of Panasonic</p>
---	--

Support for D-Link Internet cameras, including:


- DCS-900, DCS-900W (please confirm the proper firmware and set-up software: <http://www.dlink.com/products/support.asp?pid=270>)
- DCS-2100+
- DCS-3220
- DCS-5300W

	<p>Embedded Automation is proud to support D-Link Corporation products as part of mControl.</p> <p>For more information on D-Link Corporation, visit http://www.dlink.com/</p> <p>Image Courtesy of D-Link Corporation</p>
---	---

Security Systems


Support for Elk Products, Inc. technologies, including:

- ELK-M1G (Gold) Cross Platform Control

	<p>Embedded Automation is proud to support Elk Products, Inc. products as part of mControl.</p> <p>For more information on Elk Product, Inc., visit http://www.elkproducts.com/index.html</p> <p>Image Courtesy of Elk Products, Inc.</p>
---	--


Support for Digital Security Controls (DSC) technologies, including:

- DSC PowerSeries Security Systems

	<p>Embedded Automation is proud to support Digital Security Controls (DSC) products as part of mControl.</p> <p>For more information on Digital Security Controls (DSC), visit https://www.dsc.com/Home.aspx</p> <p>Image Courtesy of Digital Security Systems (DSC)</p>
---	---

Support for Honeywell Security technologies, including:


- ADEMCO VISTA Commercial Burglary Partitioned Security System With Scheduling

	<p>Embedded Automation is proud to support Honeywell Security products as part of mControl.</p> <p>For more information on Honeywell Security, visit http://www.security.honeywell.com/</p> <p>Image Courtesy of Honeywell Security.</p>
---	--

HVAC Systems


Support for HAI thermostats, including:

- Omnistat RC series thermostats

	<p>Embedded Automation is proud to support Home Automation, Inc. (HAI) products as part of mControl.</p> <p>For more information on Home Automation, Inc., visit http://www.homeauto.com/Products/Omnistat/rc80.asp</p> <p>Image Courtesy of Home Automation, Inc. (HAI) © 2006</p>
---	---

Support for RCS thermostats, including:


- TXB16 (X10) Thermostat
- TZ16 (Z-Wave) Thermostat

	<p>Embedded Automation is proud to support Residential Control Systems Inc. products as part of mControl.</p> <p>For more information on Residential Control Systems Inc., visit http://www.resconsys.com/index.htm</p> <p>Image Courtesy of Residential Control Systems Inc. © 2006</p>
---	--

Irrigation Controllers

Support for SimpleHomeNet irrigation controllers, including:

- EZRain V1 Irrigation Controller

	<p>Embedded Automation is proud to support SimpleHomeNet products as part of mControl.</p> <p>For more information on SimpleHomeNet, visit http://simplehomenet.com/</p> <p>Image Courtesy of SimpleHomeNet © 2006</p>
---	---

IR Support

Support for Global Caché Network Adapter technologies, including:

- GC-100-xx Network Adapters
- GC-IRL (IR Learner) – used to input IR commands
- GC-IRE (IR Extender) – used to input IR commands
- GC-RG1 (IR Receiver) – used to input IR commands



Embedded Automation is proud to support **Global Caché** products as part of mControl.

For more information on **Global Caché**, visit <http://www.globalcache.com/>

Image Courtesy of **Global Caché** © 2005

Support for USB UIRT IR Adapter technologies, including:

- USB UIRT IR adapter – used to learn and blast IR commands



Embedded Automation is proud to support **USB UIRT** products as part of mControl.

For more information on **USB UIRT**, visit <http://www.usbuirt.com/overview.htm>

Voice Recognition Support

Support for One Voice Technologies, including:

- Media Center Communicator™ 2.1 software




Embedded Automation is proud to support **One Voice Technologies** products as part of mControl.

For more information on **One Voice Technologies**, visit <http://www.onev.com/mcc/index.htm>

Image Courtesy of **One Voice Technologies** © 2006

INSTEON Protocol

	<p>Embedded Automation is proud to support the INSTEON protocol as part of mControl.</p> <p>For more information on INSTEON, visit http://www.insteon.com/</p> <p>Image Courtesy of SMARTHOME © 2003</p>
---	---

INSTEON Adapters

Support for INSTEON adapters, including:

- 2414U PowerLinc Controller (USB)
- 2414S PowerLinc Controller (Serial)
- 2814U PowerLinc Controller (USB with no pass-through outlet)

By default, mControl is configured to work with an INSTEON 2414U or 2814U. To use an INSTEON 2414S, navigate to the C:\Program Files\Embedded Automation\mControl\server directory and use a text editor to edit the mServer.exe.xml file. Locate the section associated with the "2414x" adapter and change the port to match the COMx port where the 2414S is located.

```
<adapter base="2414x" load="Y" assembly="EA.InsteonX10.dll"
  driver="EmbeddedAutomation.mServer.Adapters.Insteon2414Manager">
  <aparam name="DISPLAY-AS" value="PowerLinc"/>
  <aparam name="Description" value="INSTEON PowerLinc Adapter"/>
  <aparam name="Supports" value="INSTEON|X10|X10PDIM"/>
  <aparam name="AProtocol" value="INSTEON"/>
  <aparam name="Port" value="COM1"/>
  <aparam name="DebugLevel" value="5"/>
  <aparam name="STARTUP_CHECK_LINK" value="true"/>
  <aparam name="STARTUP_CHECK_STAT" value="true"/>
  <aparam name="DisableX10Control" value="false"/>
  <aparam name="X10ThermoRqWait" value="8500"/>
  <aparam name="MapX10ToINST" value="M15=00.5A.DD"/>
</adapter>
```



There are different versions of the 2414U PowerLinc adapters. The following table describes the versions and their compatability with mControl:

Adapter Version	Adapter Firmware Version	Adapter SALad Version (download software area)	Comments
v1.7	v2.13	Uses TimerCoreApp v1.11 or higher	Preferred for mControl compatibility.
v1.6	v2.12	Preferably TimerCoreApp v1.00 or higher	TimerCoreApp v1.06 or higher must be used to receive paddle feedback from switches
v1.4 or below	v2.08 or below	CoreApp	Will work, but some INSTEON commands may be lost due to non-queuing capability of the older firmware. We recommend that you contact Smarthome/INSTEON to upgrade to the v1.6 of the Adapter.

INSTEON Devices

Support for most INSTEON devices, including:

Device	Description	Dimmable
2476D	SwitchLinc V2 Dimmer	Yes
2476S	SwitchLinc V2 Relay	
2456D3	LampLinc V2 3-Pin	Yes
2456S3	ApplianceLinc V2 3-Pin	
2486D	KeypadLinc V2	Yes
2876DB	ICON SwitchLinc	Yes
2876SB	ICON SwitchLinc	
2856DxB	ICON Lamp Dimmer	Yes
2856SxB	ICON Appliance Module	
EZRain V1	Irrigation Controller	N/A

The following table summarizes INSTEON device behavior:

Previous State	Command	Result
OFF	ON	On at Preset On value
OFF	BRIGHT *	ON at x%, where x is defined by the mControl dim/bright granularity for the device
OFF	DIM *	OFF
OFF	OFF	OFF
ON	ON	ON at 100%
ON	BRIGHT *	ON – (y + x)%, where x is defined by the mControl dim/bright granularity for the device and y is the previous level. Maximum value is 100%
ON	DIM *	ON – (y – x)%, where x is defined by the mControl dim/bright granularity for the device and y is the previous level
ON	OFF	OFF

* For non-appliance devices only

Compatible with most INSTEON transceivers and remotes, including:

- 2430 - ControlLinc
- 2442 - SignalLinc RF

Two-Way INSTEON Communication

Link Databases

Like all INSTEON devices, the 2414U adapter has a “link database” (for the 2414U, this is sometimes called the “PLC Database”). This link database has a list of all “linked” INSTEON devices.

For security reasons, the 2414U Adapter automatically obfuscates all INSTEON messages from devices not in the link database. Ostensibly, this is to ensure that your neighbor can not see the operation of your devices but you will be able to see all activity associated with your devices.

mControl can automatically link all entered devices entered within the 2414U INSTEON Adapter's link database.

To enable/disable automatic linking and status checking upon start-up of mControl, modify the STARTUP_CHECK_LINK (add an entry in the link database) and STARTUP_CHECK_STAT (get the status of the device) parameters within the “mServer.exe.xml” file, located in the “C:\Program Files\Embedded Automation\mControl\server” directory.

```
<adapters>
  <adapter base="2414U" load="Y" assembly="mServerAdapters.dll"
    driver="EmbeddedAutomation.mServer.Adapters.Insteon2414Manager">
    <aparam name="DISPLAY-AS" value="2414U"/>
    <aparam name="OTHER-NAMES" value="2414U"/>
    <aparam name="DESCRIPTION" value="INSTEON PowerLinc USB adapter"/>
    <aparam name="SUPPORTS" value="INSTEON|X10"/>
    <aparam name="APROTOCOL" value="INSTEON"/>
    <aparam name="PORTS" value="USB"/>
    <aparam name="STARTUP_CHECK_LINK" value="true"/>
    <aparam name="STARTUP_CHECK_STAT" value="true"/>
  </adapter>
```

Recognizable values are:

- *true* – enable automatic linking or status checking upon start-up
- *false* – disable automatic linking or status checking upon start-up



Please note, if you have a large database, upon start-up the automatic linking and status checking process may take a few minutes. Normally, this is unnoticeable because this happens before an mControl client is accessed.

mControl uses the following methods to update the 2414U's link database:

- Upon start-up, if STARTUP_CHECK_LINK is enabled, mControl tries to link all the INSTEON addresses within the mControl database.
- Upon entry of an INSTEON device using the Add/Edit Device page, mControl will attempt linking of the new device
- Upon deletion of an INSTEON device using the Edit Device page, mControl will attempt to remove the link of the deleted device
- Upon modification of an INSTEON address using the Edit Device page, mControl will attempt to remove the link of the unused device and link the address of the new device

Updating Device Status

If devices are not linked, mControl can recognize status changes only if these changes are initiated by mControl – status changes from external sources, say a ControlLinc or a SwitchLinc paddle press, will not be recognized.

mControl uses the following methods to update the status of devices stored in the mControl database and shown on the screen:

- Upon start-up, immediately after the linking process, mControl inquires for the status of each device and listens for the acknowledgement message
- Upon each command or macro, mControl listens for the acknowledgement message
- If the device is linked in the PLC Database, mControl is also able to listen for acknowledgements sent by the device as a response to the initiating device.

If mControl is not updating status of the device, the following problems may exist:

- The device did not link during start-up or the add/edit process. It is recommended to either re-start mControl, re-save the device using the Edit Device page or attempt manual linking.
- There is significant traffic or noise on the powerline and the 2414U adapter did not receive the status (or acknowledgement) message. Consider moving the adapter away from noisy electrical components (e.g., computer), relocate any X10 devices that are in the adapter's proximity (they can interfere with normal processing), reduce the traffic on your INSTEON network by reducing the number of external links.

Macro Triggering and Real-time Status Changes from SwitchLinc Paddle Presses

As shipped from the factory, the 2414U PowerLinc Adapter can not “hear” paddle press messages originating from SwitchLinc. As a result, mControl can not show any status changes initiated by paddle presses on SwitchLinc devices.

To enable this, the 2414U and SwitchLinc must be linked to each other.

1. Link the SwitchLinc to the PowerLinc

As part of mControl normal operation, mControl will automatically create a link within the 2414U's link database upon entry of the SwitchLinc device.

2. Link the PowerLinc to the SwitchLinc

SwitchLinc devices will only send paddle press changes to devices linked to it. As shipped from the factory, 2414U does not allow for “slave” links from other devices, like SwitchLincs, due to limitations in the “SALad core application”, a software application, which manages the interface between the INSTEON connection and the computer. To enable this functionality, a new SALad core application must be downloaded to the PowerLinc. Ensure the 2414U PowerLinc Adapter is using the TimerCoreApp (v1.06)

Once these steps have been completed, it is possible to receive real-time information (<2 seconds) from SwitchLinc devices. In addition, it is possible to use SwitchLinc On or Off paddle presses for macro triggers.



While it is possible to poll for status for INSTEON devices, mControl does not use polling to ensure that there is no additional traffic on the INSTEON bus. Generally speaking, Embedded Automation

believes that polling causes unnecessary traffic which may conflict with device to device messaging – we believe that event-based messaging is best.

For more detailed information, please refer to mControl Application Note 06-0001-A.

Setting Preset On and Ramp Rates

mControl allows users to set the Preset On and Ramp Rates for the following devices:

- 2876DB ICON SwitchLinc
- 2476D SwitchLinc v2.2
- 2476D SwitchLinc v2.0
- 2486D KeypadLinc
- 2456D3 LampLinc

Please refer to the Edit Device section of this manual for additional information.

X10 to INSTEON Translator

This feature allows incoming X10 addresses to directly affect a corresponding INSTEON address. This is particularly useful for cases where hybrid systems exist and rely on a X10-based back-end controller and INSTEON-based lighting control. This is done at the “driver” level of mControl – no automation or macros are required.

Under the “2414U” <adapter> element within the XML file multiple parameters may be added to map an X10 address to a specific INSTEON address. The format of this parameter is:

```
<aparam name="MapX10ToINST" value="{X10 address}{separator}{INSTEON address}">
```


Recognizable values are:

- *X10 address* – required X10 address to listen for and translate into an INSTEON address (does not have to be in the mControl database)
- *separator* – single character to separate the X10 and INSTEON address. Valid characters are ‘:’, ‘-’, ‘=’, ‘ ’ or ‘|’.
- *INSTEON address* – INSTEON address to translate the X10 address to (does not have to be in the mControl database)

In the following sample, two X10 addresses, B3 and B4, are mapped to INSTEON addresses, 00.EF.F0 and 00.EF.F1, respectively.

```
<adapter base="2414U" load="Y" assembly="mServerAdapters.dll"
  driver="EmbeddedAutomation.mServer.Adapters.Insteon2414Manager">
  <aparam name="DISPLAY-AS" value="2414U"/>
  <aparam name="OTHER-NAMES" value="2414U"/>
  <aparam name="DESCRIPTION" value="INSTEON PowerLinc USB adapter"/>
  <aparam name="SUPPORTS" value="INSTEON|X10"/>
  <aparam name="APROTOCOL" value="INSTEON"/>
  <aparam name="PORTS" value="USB"/>
  <aparam name="MapX10ToINST" value="B3=00.EF.F0"/>
  <aparam name="MapX10ToINST" value="B4=00.EF.F1"/>
</adapter>
```

Z-Wave Protocol

	<p>Embedded Automation is proud to support the Z-Wave protocol as part of mControl.</p> <p>For more information on Z-Wave, visit http://www.z-wavealliance.org/content/modules/Start/</p> <p>Image Courtesy of Z-Wave Alliance © 2006</p>
---	---

Z-Wave Adapters

Support for Z-Wave PC adapters, including:


- Intermatic Computer Interface (Model No. HA22 – USB)
- HomePro Computer Interface (Model No. ZCU010 – USB) by ACT



For the HomePro Computer Interface For best results, we recommend using Z-Wave v4.10 or higher (Stationary Controller) firmware. Using older firmware may not provide feedback on device changes and hence, real-time client updates and macro triggers may not operate correctly.



If you have not previously used a Z-Wave adapter, you may be required to install the associated drivers – please refer to the documentation and software provided with your adapter. Upon plugging in the adapter, you will be required to provide a location for the driver files to be installed. Once the driver files are installed and your computer is rebooted, the adapters will be ready for use with mControl.





Z-Wave and mControl terminology differences should be noted:

- For Z-Wave, “controllers” are used to manage a Z-Wave network. There are two types of controllers, primary and secondary.
 - As the name implies, primary controllers are the primary controllers of the Z-Wave network and are used to set up the Z-Wave network and associated devices. Primary controllers are typically portable devices, which can manage local (“short range”) enrollment and un-enrollment of Z-Wave devices.
 - A secondary controller contains information on the Z-Wave network and the associated devices. Secondary controllers are allowed to communicate with the existing network definition, but are not allowed to add or remove devices.
- The PC-attached devices which are capable of sending Z-Wave protocols are typically secondary controllers, though it is possible to configure these as primary controllers.
- For mControl, all PC attached devices used to interface to a home automation protocol are called adapters. Hence, as long as device is attached to the PC and is capable of sending out Z-Wave protocol messages, and regardless of configuration as a Z-Wave primary or secondary controller, in terms of mControl terminology, it is considered an adapter.

Real-time Information Display

mControl can receive status changes from devices in real-time, allowing for up-to-date status information on devices and macro triggering. The speed of updates is dependent on the polling rate defined for the Z-Wave driver. This rate is set within the mServer.exe.xml file.

```
<adapter base="ZWCTRL" load="Y" assembly="EA.ZWAVE.dll"
driver="EmbeddedAutomation.mServer.Adapters.ZWaveManager">
  <aparam name="DISPLAY-AS" value="Z-Wave Controller"/>
  <aparam name="OTHER-NAMES" value="Z-Wave PC COntroller"/>
  <aparam name="Description" value="Z-Wave USB Controller"/>
  <aparam name="Supports" value="ZWAVE"/>
  <aparam name="AProtocol" value="ZWAVE"/>
  <aparam name="Ports" value="USB|COM1|COM2|COM3|COM4"/>
  <aparam name="IniPorts" value="USB"/>
  <aparam name="DebugLevel" value="5"/>
  <aparam name="PollingSeconds" value="10" note="zero means no polling.
Allowed range: {0-3600} seconds"/>
</adapter>
```



To ensure robust network use and to comply with regional requirements, polling rates should be kept as high as possible – a simple rule of thumb is 1 second per device, so for 30 devices, use 30 seconds.

Z-Wave Devices

Support for most Z-Wave devices, including:

<i>Device Type</i>	<i>Devices Validated</i>
Binary Switches	<ul style="list-style-type: none"> ▪ Intermatic HA01: In-Wall Receptacle ▪ Intermatic HA02: Plug-in Appliance Module ▪ Intermatic HA04: Outdoor Lighting Module
Multi-Level Switches	<ul style="list-style-type: none"> ▪ Intermatic HA03: Plug-in Lamp Module ▪ Intermatic HA06: In-Wall Switch/Dimmer
Thermostats	<ul style="list-style-type: none"> ▪ RCS TZ16 Thermostat

Works with the following Z-Wave devices, including:

<i>Device Type</i>	<i>Devices Validated</i>
Remotes	<ul style="list-style-type: none"> ▪ Intermatic HA07: Master Remote Control ▪ Intermatic HA09: Handy Remote Control

Remotes can be used as Primary or Secondary controllers.

The following table summarizes multi-level Z-Wave device behavior:

Previous State	Command	Result
OFF	ON	On at Preset On value
OFF	BRIGHT *	ON at x%, where x is defined by the mControl dim/bright granularity for the device
OFF	DIM *	OFF
OFF	OFF	OFF
ON	ON	If below Preset On value, then goes to Preset On value, else ON at 100%
ON	BRIGHT *	ON – (y + x)%, where x is defined by the mControl dim/bright granularity for the device and y is the previous level. Maximum value is 100%
ON	DIM *	ON – (y – x)%, where x is defined by the mControl dim/bright granularity for the device and y is the previous level
ON	OFF	OFF

Z-Wave Adapter Utility

mControl setup installs a utility, called the Z-Wave Adapter Utility, which can be used to quickly and easily configure your Z-Wave adapter and associated network. Use the Z-Wave Adapter Utility to:


- Connect to the adapter
- Define the “controller” configuration for the adapter:
 - Reset the adapter to act as a Z-Wave primary controller
 - Reset the adapter to act as a Z-Wave secondary controller
 - Receive network information from another controller (if the adapter is configured as a secondary controller)
 - Send network information to another controller (if the adapter is configured as a primary controller)
- Quickly add/remove devices to the Z-Wave adapter/controller.




Only one software component can be connected to the Z-Wave adapter at one time.

- ***Upon starting the Z-Wave Adapter Utility and attempting to connect to the adapter, you will be prompted to stop the mControl Automation Service.***
- ***Upon leaving the Z-Wave Adapter Utility, a dialog box will prompt you to restart the mControl Automation Service.***

The Z-Wave Adapter Utility is automatically installed and is accessible from the “Tools” section of the mControl program area:



Once started, the following Windows-based dialog box is shown:



Connection Options

- **Port** – select the COM or USB port on which the Z-Wave adapter is connected to. (Only the COM ports that are available on the machine are shown.)
- **Devices Poll Interval (sec)** – the polling rate for Z-Wave devices within the Z-Wave Adapter Utility.

Note that this is a different setting than the mControl polling rate, which is set within the mServer.exe.xml file.

- **Connect** – connect to the selected Z-Wave adapter on the port specified.
- **Disconnect** – disconnect from the Z-Wave adapter
- **Refresh Devices List** – refresh the device list to the get latest information

Controller Options

- **Reset Controller** – use this button to configure the adapter as a Z-Wave primary controller.
 - There can only be one primary controller in your Z-Wave network.
 - To add and remove devices, the primary controller must be located within a close proximity to the devices being added or removed. Hence, it may not be prudent to set your adapter as a primary controller.
- **Start Receive Configuration** – use this button to receive network information from a primary controller. This button will set the Z-Wave adapter to be a secondary controller.
 - For example, if you are using a HA07 as a primary controller, you can transmit the network information to the Z-Wave adapter connected to your PC. Press the “Receive Configuration” button in the Z-Wave Adapter Utility, then press and hold the “Include” button on the HA07. “Copy” will be shown in the LCD display. Release the “Include” button. Press and release the Channel 1 ON/DIM button on the primary controller. “TA” which stands for “Transmit ALL data” will be shown next to the copy. After about 10 to 20 seconds, the Z-Wave Adapter Utility will complete receiving all the network data and display it in the Z-Wave Adapter Information window.
- **Cancel Receive Configuration** – use this button to abort the “Start Receive Configuration” request.
- **Start Send Configuration** – use this button to send network information to a secondary controller.
 - For example, if you have configured the Z-Wave adapter as the primary, you may want to transfer the network configuration to your HA07 remote.
- **Cancel Send Configuration** – use this button to abort the “Start Send Configuration” request.
- **Start Transfer Primary Role** – use this button to transfer the network information and primary role to another adapter. This button will set the Z-Wave adapter to be a secondary controller.
- **Cancel Transfer Primary Role** – use this button to abort the “Cancel Transfer Primary Role” request.

Device Options

If the adapter has been configured as a primary controller, the following Device Management Options are available:

- **Start Add Device** – use this button to initiate adding a Z-Wave device to the primary controller (adapter).



Z-Wave devices may not be able to be added if there were previously associated with another network. In this scenario, you may try to remove the device and then add the device.

- **Cancel Add Device** – use this button to abort the process of adding a Z-Wave device to the primary controller (adapter).
- **Start Remove Device** – use this button to initiate removing a Z-Wave devices from the primary controller (adapter).
- **Cancel Remove Device** – use this button to abort the process of removing a Z-Wave device from the primary controller (adapter.)
- **ID of Device To Replace, Remove or Rediscover** – this display window provides a list of devices in the network, which can be selected for replacement, deletion or rediscovery.
- **Replace Failed Node** – use this button to replace a failed node. This button deletes the node entry from the network and adds a replacement device with the address previously used by the failed device. This is useful because deleting and then adding a device may not result in the same node addressing within the network.
- **Delete Failed Node** – use this button to delete a failed node from the network. This button deletes the node entry from the network.
- **Rediscover Node** – use this button to rediscover Z-Wave information about the node.



Please note, older adapters/firmware may have problems with unenrolling and then re-enrolling devices. Please verify your network before adding devices to mControl.

mControl Automation Service Options

- **Start** – Start the mControl Automation Service. This button will typically be selected to restart the service after completing configuration using the Z-Wave Adapter Utility and disconnecting from the adapter.
- **Stop** – Stop the mControl Automation Service. This button will typically be selected before connecting to the adapter.
- **Restart** – Restart the mControl Automation Service.
- **Service Status** – displays the status of the mControl Automation Service
- **Exit** – Exit the Z-Wave Adapter Utility
- **About ...** – Information about the Z-Wave Adapter Utility

Z-Wave Adapter Information

- **Network Configuration** – this window provides the network configuration stored within the Z-Wave Adapter.
- **Log** – this window provides a real-time display of network activity, as viewed by the Z-Wave adapter.

Adding Z-Wave Devices to mControl

Use the following methods to add Z-Wave devices to mControl (shown in order of typical use):

- **If the Z-Wave adapter is defined as a secondary controller**

If not already set, use the Z-Wave Adapter Utility to define the Z-Wave adapter as a secondary controller.

With the adapter configured as a secondary controller, you will not be able enroll or un-enroll devices from within mControl. You must use the Z-Wave Adapter Utility to receive the network information, including devices defined on the network, from a primary controller. Follow the instructions provided on your primary controller to replicate (copy) the primary controller settings to a secondary controller to initiate this process.

Once this has been completed, use the mControl Edit Device page to associate device names to the corresponding Z-Wave network device enrolled IDs.

- **If the Z-Wave adapter is defined as a primary controller**

If not already set, use the Z-Wave Adapter Utility to define the Z-Wave adapter as a primary controller.

Once the Z-Wave adapter has been reset as a primary controller, devices IDs can be directly enrolled or un-enrolled to the adapter (primary controller). This can be done from either the Z-Wave Adapter Utility or directly within mControl (Edit Device page).

Once this has been completed, use the mControl Edit Device page to associate device names to the corresponding Z-Wave network enrolled device IDs.

Removing Z-Wave Devices from mControl

Use the following methods to remove Z-Wave devices from mControl (shown in order of typical use):

- **If the Z-Wave adapter is defined as a secondary controller**

Remove the devices from your primary controller. You must use the Z-Wave Adapter Utility to receive the updated network information from the primary controller. Follow the instructions provided on your primary controller to replicate (copy) the primary controller settings to a secondary controller to initiate this process.

Once this has been completed, you must use the mControl Edit Device page to delete the corresponding Z-Wave network device IDs. This removes the device from the mControl database.

- **If the Z-Wave adapter is defined as a primary controller**

This can be done from either the Z-Wave Adapter Utility or directly within mControl (Edit Device page).

- From the Z-Wave Adapter Utility – select the “Start Remove Device” button to remove the device from the network.
- From within mControl (Edit Device page) – select the “Unenroll” button to remove the device from the network.

Once this has been completed, you must use the mControl Edit Device page to delete the corresponding Z-Wave network device IDs. This removes the device from the mControl database.

X10 Protocol

X10 Adapters

Support for most X10 adapters, including:

- CM11A Adapter (Serial), CM11U Adapter (Serial), CM12U Controller (Serial)
- CM15A "ActiveHome" (USB)
- CM17A "Firecracker" Adapter (Serial)

Please note the following supported characteristics for X10 adapters:

Adapter	Protocol	Command Send (Power line)	Command Receive (Power line)	Command Send (RF)	Command Receive (RF)
2414x	X10 (Standard)	Supported	Supported <i>Used to update X10 module status</i>	Not supported	Not Supported <i>Use X10 Transceiver to translate RF to PLC signal</i>
CM11A, CM11U, CM12U	X10 (Standard and Extended)	Supported	Supported <i>Used to update X10 module status</i>	Not supported	Not Supported <i>Use X10 Transceiver to translate RF to PLC signal</i>
CM15A	X10 (Standard)	Supported	Supported <i>Used to update X10 module status</i>	Not Supported	Not Supported <i>Use X10 Transceiver to translate RF to PLC signal</i>
CM17A	X10 (Standard)	N/A	N/A	Supported <i>Requires X10 transceiver</i>	Not supported
W800RF32A	X10	N/A	N/A	Not Supported	Supported



By default, the CM11 driver is enabled. In addition, the COM port associated with the CM11A adapter can be left open (to allow for receipt of incoming X10 commands) or closed after messages are sent (to allow for other applications to use the COM port to have access). This setting can be enabled within mServer.exe.xml file:

```
<adapter base="CM11A" load="Y" assembly="EA.InsteonX10.dll"
driver="EmbeddedAutomation.mServer.Adapters.CM11AManager">
  <aparam name="DISPLAY-AS" value="CM11A"/>
  <aparam name="OTHER-NAMES" value="CM11A|CM12A"/>
  <aparam name="Description" value="ActiveHome X10 Serial Adapter"/>
  <aparam name="Supports" value="X10|X10THERMO"/>
  <aparam name="AProtocol" value="X10"/>
  <aparam name="Ports" value="COM1|COM2|COM3|COM4"/>
  <aparam name="IniPorts" value="COM1"/>
  <aparam name="KeepPortOpen" value="true"/>
  <aparam name="ResponseTimeout" value="500"/>
  <aparam name="DebugLevel" value="5"/>
</adapter>
```



For X10-based device macro triggers, you must use CM15A or CM11A adapters. To use a X10 RF remote to initiate a device you must use an X10 Transceiver (e.g., TM751) to translate the X10 RF signal to X10 PLC signal – once on the powerline, the adapter can receive the incoming command.



By default, the W800RF32A is not enabled. To enable the W800RF32A driver, modify the load settings for the W800RF32A driver to "Y". You must ensure that no other serial port drivers conflict.

```
<adapter base="W800RF" load="Y" assembly="EA.InsteonX10.dll"
driver="EmbeddedAutomation.mServer.Adapters.W800RF32Manager">
  <aparam name="DISPLAY-AS" value="W800RF32A"/>
  <aparam name="Description" value="WGL W800RF32A PC Receiver"/>
  <aparam name="Supports" value="X10"/>
  <aparam name="AProtocol" value="X10RF"/>
  <aparam name="Port" value="COM1"/>
  <aparam name="KeepPortOpen" value="true"/>
  <aparam name="ResponseTimeout" value="500"/>
  <aparam name="DebugLevel" value="5"/>
</adapter>
```

X10 Devices

Support for most X10 modules, including:

- AD10 – Din Rail Mounted Appliance Module
- AM12U – Plug-in Appliance Module
- AM466 – Appliance module
- LD11 – Din Rail Mounted Lamp Module
- LM12U – Plug-in Lamp Module
- LM14A – 2-Way Lamp Module
- LM15 – Screw-in Lamp Module
- LM465 – Lamp module
- PAM21 – 2-Way, 2-Pin Appliance Module
- RLM20 - Remote Controlled Lamp Module
- RSC15 - Remote Controlled Chime
- SSR227 – Super Socket Wall Outlet
- W467 - Dimmable Wall Switch
- WS12A – Decorator Dimmer Wall Switch
- WS14A – Decorator Style Companion Wall Switch

The following table summarizes X10 device behavior:

Previous State	Command	Result
OFF	ON	ON – 100%
OFF	BRIGHT *	Standard X10: ON – 100% Extended X10: ON – x%, where x is defined by mControl dim/bright granularity for the device.
OFF	DIM *	Standard X10: ON – 100% Extended X10: ON – 0%, where x is defined by mControl dim/bright granularity for the device.
OFF	OFF	OFF
ON	ON	ON – at previous level
ON	BRIGHT *	ON – (y + x)%, where x is defined by the mControl dim/bright granularity for the device and y is the previous level
ON	DIM *	ON – (y – x)%, where x is defined by the mControl dim/bright granularity for the device and y is the previous level
ON	OFF	OFF

* For non-appliance devices only


Compatible with most X10 transceivers, including:

- W800RF32A – Wireless RF Transceiver
- RR501 - Transceiver Module
- TM13U - RF Transceiver
- TM751 - RF Transceiver

Compatible with most X10 sensors and remotes, including:

- HR12A - PalmPad Remote Control
- KR19A - Remote Control Module (Keychain)
- KR22A - Remote Control Module
- MS14A - EagleEye™ Indoor/Outdoor Motion Sensor
- MS16A - ActiveEye™ Indoor/Outdoor Motion Sensor
- RSS18 - Remote Wall Switch
- SS13A - Remote Wall Switch
- SS15A - Remote Wall Switch
- UR73A - Universal Remote with X10

Leviton X10 Devices

	<p>Embedded Automation is proud to support Leviton Mfg. Company Inc. X10 products as part of mControl.</p> <p>For more information on Leviton Mfg. Company Inc., visit http://www.leviton.com/</p> <p>Image Courtesy of Leviton Mfg. Company Inc.</p>
---	--

mControl provides extended X10 support for Leviton dimmable devices including:

- Dimming Switches (e.g., HMC10)
- Dimming Modules (e.g., HCP03)

Limitations and Recommendations

1. All adapters must be attached to the PC where the mControl Automation Service is installed.
2. Embedded Automation does not recommend systems with multiple adapters co-located on the same PC as the mControl Automation Service.
 - a. If there are multiple receiving adapters (e.g., 2414 PowerLinc and CM15A), redundant received commands may lead to erroneous results.
 - b. If there are multiple sending adapters, commands sent over different adapters around the same time may lead to erroneous results due to network congestion and collisions.


mControl Installation

Step 1 - Install mControl software

If you are installing mControl for the first time, skip directly to the “Download the Latest Version of mControl” step.

Upgrading mControl


If you are upgrading mControl to a more recent version, please uninstall the previous version. Use the Windows’ “Add or Remove Programs” utility to uninstall the previous version. To use this utility, press the Start button, then select Control Panel and finally select “Add or Remove Programs”. Cursor to mControl and press the “Remove” button to uninstall the previous version.





This uninstall process will not remove any of your existing information – all zone, device, adapter and license information will be kept for subsequent versions.

Download the Latest Version of mControl

As a customer (or as a trial user), the first thing that you will need to do is download the most recent mControl version from the Embedded Automation website.




Once the download has initiated, “Save” mControl to your hard drive – for example, in the “My Received Files” area.




Extract and Install mControl

The downloaded file is a ZIP file, so you must use WinZip or equivalent to extract the contents.




Once the contents are extracted, run the mControl setup file (mControlSetup.msi) you received from Embedded Automation.




The installation process can take several minutes and will automatically install all of the software required for mControl. Any changes, for example, upgrading to the latest version of the mControl database, are also automatically done as part of the installation process.



You must agree with the End-User License Agreement (EULA) to continue installation. Please read and accept to continue.



You will be asked if you wish to install third party software.




The following third party software components are a part of mControl:

Component	Description
X10 CM15A Adapter	Low level driver software to allow mControl to communicate with a X10 CM15A adapter. File: <i>ahscript_setup.exe</i>
Axis IP camera ActiveX component	ActiveX component to allow mControl to display video stream from Axis cameras: File: <i>amc_redist.exe</i>


By default, all Third Party software components will be installed. Unselect if you do not want these installed. If you do not install these components during installation, these components can be installed later by navigating to the C:\Program Files\Embedded Automation\mControl\third party directory and selecting the file required.

You must provide a location where to install mControl and for whom the installation is for. By default, mControl is installed in the C:\Program Files\Embedded Automation\mControl directory and is available for every user ("Everyone"). ***If you are not sure, please select the defaults provided.***

If you intend to use a MCE Extender or make the software available for other users, select "Everyone".




After confirmation of these settings, mControl will be installed. This may take several minutes.




Once completed, the Readme.rtf file will be shown. This file provides information on your mControl software, including:

- Terms and Conditions of Use
- How to install your user license (from CD or online purchase)
- How to contact Embedded Automation technical support
- Information on mControl versions



After reading the readme.rtf file, the installation will be complete.




Step 2 - Start mControl software

Starting mControl using an Internet Explorer Browser

You can start mControl by using the Windows “Start” button, then the “All Programs” option, then the “mControl” folder and finally, the “mControl” program.




Alternatively, you can also use Internet Explorer. Open Internet Explorer (IE) and enter the following line in the address bar, <http://localhost:29990/Default.aspx>.



It is highly recommended that you delete all content from your Temporary Internet Files location, before installation, to avoid any conflicts with previous content.

Starting mControl within Media Center

You can access mControl by selecting “More Programs” area within “Media Center”.



Step 3 – Activating mControl


mControl Trial Version

mControl v1 (Home Edition) is provided for a 30-day trial from the Embedded Automation web site. A copy-protection mechanism manages this limitation. mControl will show the number of days remaining in the trial when the “Zone View” screen is accessed. The trial version of mControl offers full software functionality for the duration of the trial. Upon expiration, mControl will continue to operate as usual, however, automation commands will only be sent to the first three defined devices. Any re-installation or tampering with system date and/or the mControl license will cause automatic expiration of the copy protection. Please contact Embedded Automation to extend your 30-day trial by emailing support@embeddedautomation.com.

Replace the mControl Trial License with a Purchased License

To activate your software, you will have to purchase a software license. Upon completing your purchase, you will be emailed a new license file, or for those retailers which provide a CD, the license file will be on your CD. Your purchased license file will be called named “**mServer.exe.lic**” or “**mServer.exe.lic.cpy**”. This license file is not activated and you will have 10 days to activate this file.


Copy the purchased license file from the CD and paste it into the following location: C:\Program Files\EmbeddedAutomation\mControl\Server. Please ensure that you replace the existing demo license (also called “**mServer.exe.lic**”) with the purchased license – this may require that you rename the purchased license to “**mServer.exe.lic**” if it was previously named “**mServer.exe.lic.cpy**”.




Once the purchased license is copied to the proper location, mControl must be restarted to use the new license. Reboot the computer or use the mControl Service Manager to restart mControl.

Activating the mControl License

Once mControl has been restarted, you will be prompted to activate your purchased license upon reentering mControl using either your Internet browser or Media Center interface. This activation process will remove all time restrictions from the software. You have 10 days to complete this activation.



Upon selecting to activate, you will be sent to the "Activation" page, where the mControl license is activated.



There are two ways to activate your mControl license:


1. **Web Activation** – this is the recommended license activation procedure, as it is completed automatically. You will need a broadband connection.

To perform a web activation, press the “Activate” button beside the “Automatic via web” label. Once pressed, mControl will automatically download the special codes to activate the mControl license.



Web activation may take several seconds – please be patient – DO NOT press the “Activate” button multiple times.

Once successful, the box at the bottom left of the screen will turn green.



2. **Manual Activation** – this activation requires you to call or email mControl support. mControl support will provide a special code to activate your license. This special code will be entered in the field by the “Manual Activation Key” label.



The activated license will be associated to the machine on which mControl is installed. To move the license to another machine, you will have to contact Embedded Automation.

Using mControl with a Dial-up Internet Connection

Since the mControl UI client is a web-based interface, Windows and Internet Explorer assume an active Internet connection. It is possible to use mControl without an active Internet connection. If you are running mControl without an active Internet connection, for example, if you normally use dial-up to connect to the Internet. Use the following guidelines:

- Use the mControl short cuts provided under the “All Programs ...” section. This will work for either running mControl using Internet Explorer or the Media Center interface. For Media Center users, you can also select mControl from the “More Programs” area.
- Please ensure that the “Work Offline” setting is not selected. This option is found under the “File” menu option in Internet Explorer. If “Work Offline” is checked, you may receive frequent reminders to connect to the Internet if there is no active Internet connection already established.
- For dial-up customers, we recommend using the “Dial whenever a network connection is not present” setting. This setting can set using Internet Explorer “Tools” menu option, then selecting “Internet Option” under the “Connection” tab.

Using mControl Software

mControl Components

mControl (User Interface) Client

The mControl Client has been designed for Microsoft XP Media Center Edition (MCE) 2005. All operation is available via the “10 foot interface”. The user interface has been designed to be fully functional with a remote control. Text entry is handled via triple-tap input.

However, the mControl Client is also viewable in a browser. The user interface can work with a mouse. Text entry can also be accomplished via keyboard.

The mControl Client can be operated via a touch screen interface, though there is no provision for entering information, only controlling automation.

mControl (Automation) Service

The mControl Service, as the name implies, manages the automation sub-system for mControl. The mControl Service has a built-in web server and provides the base user interface to the mControl Client.

The mControl Service runs as a Windows Service called “mHome Automation Service” – the process name for the mControl Service is “mServer.exe”. The mControl Service will run automatically upon boot-up, does not require any user to be logged into Windows and will run until the PC is turned off.




The mControl Service manages all macro operation. Hence, the PC must be on and mControl Service must be running, for all macros to execute at their required times and triggers.

mControl Service Manager

mControl setup installs a utility, called the mControl Service Manager, which can be used to quickly and easily stop, start and restart the mControl (Automation) Service.

The mControl Service Manager is automatically installed and is accessible from the “Tools” section of the mControl program area:



Once started, the following Windows-based dialog box is shown:



To Start the service, press the Start button. You may need to do this if mControl has stopped running.

To Stop the service, press the Stop button. You may need to do this if you need to make custom adjustments to your mControl configuration.

To Restart the service, press the Restart button. You may need to do this to re-initialize mControl.


mControl Client and Service Interaction

The mControl Service must be running for the mControl Client to be operational.

mControl User Interface

Zone View Screen

The Zone View screen, which is considered the “main menu” of mControl, provides a summary of all the defined zones and all devices within a selected zone. From this screen, you can access all of your Zones and Devices.



Zones Area

This area provides a list of all the user-defined Zones. Each Zone can hold 0 or more Devices. Zones naming is very flexible – a zone can represent:

- Actual rooms in house – for example, “Home Theater”
- A functional area of house – for example “Main Floor”
- A generic container name – for example “My Macros”

The “active” zone, or the one currently selected, is denoted by a highlighted yellow radio button. To select a new active room, cursor to it and press OK.


If there are more than 4 zones, it is possible to scroll through them by moving the cursor to the zones area and pressing either UP/DOWN or PAGE UP/PAGE DOWN.

Access to mControl Settings

The “Settings” button provides access to the configuration section of mControl.

Devices Area

This area provides a list of all the devices for the “selected” zone.







- **Device Image** – An icon or image for the device, as configured by the user
- **Device Status** – Current status of the device and is updated in real-time.
- **Device Name** – The name of the device, as configured by the user
- **Device Functions** – The functions that the device is capable of performing (e.g., ON, OFF, DIM, BRIGHT, SHOW, PLAY, etc.)

If there are more than 4 devices, it is possible to scroll through them by moving the cursor to the devices area and pressing either UP/DOWN or PAGE UP/PAGE DOWN.

Real-time Display of Device Status





Protocol	How is Device Status Changed	Real-time Status	Comments
INSTEON	Device changed by mControl <i>e.g., button press on screen</i>	✓	▪ Near instantaneous
	Device changed by remote <i>e.g., ControlInc changes value of device</i>	✓	▪ May take 1 second
	Device changed via user manually <i>e.g., via paddle press on SwitchLinc</i>	✓	▪ Requires double-linking ▪ May take 1 second
Z-Wave	Device changed by mControl <i>e.g., button press on screen</i>	✓	▪ Near instantaneous
	Device changed by remote <i>e.g., HA07 or HA09 changes value of device</i>	✓	▪ May take up to 30 seconds, depends on polling setting
	Device changed via user manually <i>e.g., via paddle press on SwitchLinc</i>	✓	▪ May take up to 30 seconds, depends on polling setting
X10	Device changed by mControl <i>e.g., button press on screen</i>	✓	▪ Near instantaneous
	Device changed by remote <i>e.g., using HR12A remote</i>	✓	▪ Near instantaneous for CM15A and W800RF32 adapter ▪ Not supported for other adapters
	Device changed via user manually <i>e.g., via paddle press on Leviton switch</i>	✓	▪ Only available for Leviton switches (which support extended X10 commands)

Switches, Lamp and Appliance Devices


Device Status	Meaning
	Device is OFF
	Device is ON at 100% value
	Device is ON at 50% value
	Device is ON at nominally 0% value




Other increments are available, depending on the granularity of dim/bright selected for the device.


Device Function	Operation	Supported With
	Turn ON device	All appliance, lamp and switch modules.
	Turn OFF device	
	DIM device 25%	All lamp and dimmer modules.
	BRIGHTEN device 25%	


HVAC (Thermometer) Devices

Device Status	Meaning
	Status information from the thermostat including: <ul style="list-style-type: none"> ▪ Current Temperature ▪ Current Setpoint(s) ▪ Mode: Auto, Heat, Cool, Off ▪ Fan Mode: Auto, On, Off


Device Function	Operation	Supported With
	View detailed information related to the thermostat	- All thermostats


Irrigation Devices

Device Status	Meaning
	Status information from the irrigation system including: <ul style="list-style-type: none"> ▪ Valve (1 through 8) status ▪ Program (1 through 4) status


Device Function	Operation	Supported With
	View detailed information related to the irrigation system	- All EZRain systems


Security System Devices

Device Status	Meaning
	Status information from the security system including: <ul style="list-style-type: none"> ▪ Ready status (grey for not ready, green for ready) ▪ Armed status (grey for not armed, red for armed)


Device Function	Operation	Supported With
	View detailed information related to the irrigation system	- All Elk security systems


Camera Devices

Device Status	Meaning
	Live video stream from the camera

Device Function	Operation	Supported With
	View detailed information related to the camera	- D-Link cameras - Axis cameras


Macro Devices

Device Status	Meaning
	Has no meaning.

Function Button	Operation	Supported With
	Execute the macro manually using the Device Function button press as the trigger	Any macro which is enabled to be displayed on the View Zone page.

Settings Screen

The Settings screen provides information about mControl and access to the various mControl configuration screens.



Settings Options

The Settings Options buttons provide the following functions:

- **Home** – goes back to the Zone View Screen
- **Manage Zones** – allows configuration of the defined zones and associated devices
- **Automation** – allows modification of existing macros or creation of macros
- **Camera** – allows configuration of cameras
- **IR Control** – allows configuration of IR functionality

Configuration Options

Configuration settings like mControl skins and location information (for sunrise/sunset calculations).


mControl Information

This section provides the following information on mControl:

- mControl copyright and license information
 - If the license is a 30-day trial license, the “Licensed to” field will be “Embedded Automation”
 - If the license has been purchased, but not activated, the “Licensed to” field will be the purchaser’s name, with a parenthetical reference that activation is required
 - If the license has been purchased and activated, the “Licensed to” field will be the purchaser’s name
- mControl version, build number and date of build information

Configuration Screen

The Configuration Screen allows modifying the personal configuration settings of mControl.




Configuration Options

The Configuration Options buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen
- **Save Changes** – saves the configuration changes and returns to the Settings screen

Configuration Settings (Main)



This section provides the following configuration options:

- **Style** – the user interface style (or “skin”)

Styles	Comments
Blue – Static	Default style - recommended for Media Center use.
Blue – Dynamic	Provides animated images based on blue background. If you are using Media Center, please be aware that animated graphics may cause performance issues because of Media Center's scaling and rendering algorithms.



If the style is changed, please empty Temporary Internet Files in Internet Explorer to ensure the previous style is removed from the cache.

- **Language** – the language used within mControl. Currently only English is supported.

Configuration Settings (Location)

CONFIGURATION

Configure sun rise/set support 2 of 2

Back Main Location

Home Save Changes

Latitude Degree Minute

49 11

North of Equator - +

Longitude Degree Minute

123 10

West of Greenwich - +

This section allows users to define their location. Location information is used to calculate sunrise and sunset values.


- **Latitude** – in Degrees and Minutes
- **North or South of Equator** – the current location’s relative position to the Equator
- **Longitude** – in Degrees and Minutes
- **East or West of Greenwich**– the current location’s relative position to Greenwich

To determine the Latitude and Longitude of your location, we recommend:
<http://www.bcca.org/misc/qiblih/latlong.html>.

This information is used to calculate sunrise and sunset times for your location. The sunrise and sunset times can be used as triggers for mControl macros (see section “Macro Configuration – Time”).

Manage Zones Screen

The Manage Zones Screen provides a summary of all the defined zones and allows changing the order for display in the Zone View page.



Manage Zone Options

The Manage Zone Options buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the current display order of the zones
- **Add Zone** – create a new zone


Zone Configuration

This section provides the following options:

- Zone Edit – by cursoring to a zone name and pressing OK, access to the Edit Zone Screen is provided
- Zone Display Order – by pressing on the UP/DOWN buttons, the display order of the zones for the Zone View Screen is modified

Add Zone Screen

The Add Zone Screen allows the creation and naming of a new zone.



Add Zone Options

The Add Zone buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the new zone


Zone Name

This section provides the following configuration options:

- **Name** – the name of the Zone (Text entry, up to 16 characters)

Edit Zone Screen

The Edit Zone Screen allows modifying the configuration of an existing zone.



Edit Zone Options

The Edit Zone Options buttons provide the following functions:

- **Back** – goes back to the Manage Zones Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the changes for the current zone and returns to the Manage Zones Screen
- **Add Device** – adds a device to the current zone; goes to the Edit Device Screen
- **Delete Zone** – deletes the current zone and returns to the Manage Zones Screen. A Zone can not be deleted if is associated with a Macro or Actions.


Zone Configuration

This section provides the following configuration options:

- **Name** – the name of the zone (Text entry, up to 16 characters)
- **Device Edit** – by cursoring to a device name and pressing OK, access to the Edit Device Screen is provided
- **Device Display Order** – by pressing on the UP/DOWN buttons, the display order of the devices for the Zone View Screen is modified

Edit Device Screen

The Edit Device Screen allows modifying the configuration of an existing or new device.



Edit Device Options

The Edit Device Options buttons provide the following functions:

- **Back** – goes back to the Edit Zone Screen
- **Home** – goes back to the Zone View Screen
- **Save Changes** – saves the changes for the current device and returns to the Edit Zone Screen
- **Delete Device** – deletes the current device and returns to the Edit Zone Screen. A Device can not be deleted if it is associated with an Action within a Macro.

Device Configuration Menu

Use this menu system to access the various configuration settings for a device:

- **Main** – Define the address, adapter and image for the device
- **Advanced** – Defined additional parameters for the device

Device Settings (Main)

The screenshot shows the 'EDIT DEVICE' screen in the mControl interface. On the left, there are buttons for 'Back', 'Home', 'Save Changes', and 'Delete Device', along with a small icon of a ceiling light. The main area is titled 'Configure main options' and '1 of 2'. It features a 'Main' tab (highlighted in green) and an 'Advanced' tab. The configuration fields include:

- Name:** A text field containing 'Main Entry'.
- Adapter:** A dropdown menu showing '2414U-INSTEON' with minus and plus buttons.
- Module:** A dropdown menu showing '2476S' with minus and plus buttons.
- Insteon Address:** A text field containing '00.56.34'.
- Image:** A dropdown menu showing 'Ceiling Light' with minus and plus buttons.

This section provides the following configuration options:

- **Name** – the name of the device (Text entry, up to 16 characters)
- **Adapter** – the adapter used to communicate with this specific device, supported adapters include:

Adapter	Protocol	Interface	Comments
Z-Wave Adapter	Z-Wave	USB or Serial	Any Z-Wave compliant adapter (can be defined either as a primary or secondary controller)
CM11A	X10	Serial	Use this selection for CM11U and CM12U operation
CM15A	X10	USB	Also known as ActiveHome Pro
CM17A	X10	Serial	Also known as Firecracker



The Edit Device screen will change depending on the type of adapter selected.

- **Port** – the serial communication port to use. Valid ports are COM1, COM2, COM3 and COM4. This option is only available for serial communications.
- **Module** – The INSTEON or X10 module used to control this specific device. The following modules are provided on the list:

Module	Protocol	Description
Elk M1	Elk	Elk M1Gold Security System
Binary Switch	Z-Wave	Any Z-Wave binary (appliance) switch
Multi-Level Switch	Z-Wave	Any Z-Wave multi-level switch
Z-Wave Thermostat	Z-Wave	Any Z-Wave thermostat
2456Dx	INSTEON	LampLinc V2 Dimmer
2456Sx	INSTEON	ApplianceLinc V2 Switch x-pin
2476D	INSTEON	SwitchLinc V2 Dimmer
2476S	INSTEON	SwitchLinc V2 Relay
2486D	INSTEON	KeypadLinc V2 Switch
2856DxB	INSTEON	ICON Lamp Module
2856SxB	INSTEON	ICON Appliance Module
2876DB	INSTEON	ICON SwitchLinc Dimmer
2876SB	INSTEON	ICON SwitchLinc Relay
EZRain	INSTEON	EZRain Irrigation System
HCP03	Extended X10	Leviton Dimmable Lamp Module
HCM10	Extended X10	Leviton Dimmable Switch
TXB16	X10	RCS TXB16 Thermostat
AM466	X10	Appliance Module
LM14A	X10	2-way Lamp Module
LM15A	X10	SocketRocket Screw-In Lamp Module
LM465	X10	Lamp Module
PAM21	X10	2-way Appliance Module
RSC15	X10	Chime Module
SR227	X10	Super Socket Module
WS467	X10	Wall Switch Module
M16A	X10	Motion Sensor Model



If you do not see the module you want to control on this list, you can try to choose a module that most closely resembles your module. For example, if the module you are using is an "appliance" type of module, you may try to control it by setting the device to be an "AM466" module. For additional assistance, please email support@embeddedautomation.com



All INSTEON devices added to mControl zones will automatically be added to the 2414U PowerLinc's PLC Database, thereby allowing the PowerLinc to recognize the device during 2-way communications. If the device is deleted from the mControl zone, it will be automatically removed from the PowerLinc's PLC Database. This eliminates the need for the user to do manual linking and unlinking.



Z-Wave modules are tied to the Z-Wave ID, hence this is a display only field, not editable.

- **Address** – [INSTEON only] If you have selected an INSTEON module, you will required to provide an INSTEON address. The INSTEON address is in the form of xx.xx.xx, where x is a number in the range of 0-9 and A-F (hex values). To find this address, check on the back of your INSTEON device.
- **House** – [INSTEON or X10 only] If you have selected an X10 module, you will be required to provide an X10 House Address (Spinner entry, Valid Settings: A through P)
 - For convenience, mControl remembers the last House address provided
- **Unit** – [INSTEON or X10 only] If you have selected an X10 module, you will be required to provide an X10 Unit Address (Spinner entry, Valid Settings: 1 through 16)
- **Enroll** – [Z-Wave only] If you have selected a Z-Wave adapter and it is a primary controller, you can enroll a new device in to the Z-Wave network. If your adapter is defined as a secondary controller – this button will be unavailable.



Z-Wave devices may not be able to be enrolled if there were previously associated with another network. In this scenario, you may try to un-enroll the device and then enroll.

- **Un-enroll** – [Z-Wave only] If you have selected a Z-Wave adapter and it is a primary controller, you can un-enroll a device from the Z-Wave network. If your adapter is defined as a secondary controller – this button will be unavailable.
- **Abort** – [Z-Wave only] Use Abort to stop any Enroll or Un-enroll in progress. If your adapter is defined as a secondary controller – this button will be unavailable.
- **Image** – User-selectable image for the device (Spinner entry, various images). Custom images may be added - see the Advanced mControl Functionality section of this manual.

Device Settings (Advanced)



This section provides the following configuration options:

- **Dim/Bright By** – Defines the granularity of each Dim/Bright command. For example, if you set this to 10%, the brightness levels available will be 10%, 20%, 30%, etc. Of course, this is dependent on each device's capability.
- **Preset On** – Defines the “Preset On” value for the device. That is, upon an ON command, what value the device will go on to.
- **Ramp Rate** – Defines how fast the light turns ON or OFF.

	INSTEON	Z-Wave	X10
Dim/Bright By	Supported	Supported	Supported
Preset ON	Supported for: 2876DB SwitchLinc, 2476D SwitchLinc, 2476D SwitchLinc, 2486D KeypadLinc, 2456D3 LampLinc	Supported for multi- level switches only	Not supported
Ramp Rate	Supported	Not supported	Not supported

INSTEON Ramp Rates and Preset On Options



For INSTEON devices, you must cycle power after saving the device in mControl for Preset Dim and Ramp Rates to take effect. To cycle power:

- Remove power for 3-5 seconds (until LED light goes off), wait another 3 seconds and then return power.
- Pull up on SET button for 3-5 seconds (until LED light goes off), wait another 3 seconds and then push SET button to normal position (do not depress). Be careful **NOT** to push down the SET button after this process as it will factory reset the device and lose all changes.



If the Preset On and Ramp Rate is changed manually, it is recommended that mControl be restarted to ensure that changed values are re-read into mControl's database.

mControl Value for "Ramp Rate"	Corresponding LED Value if done manually
0.1 sec	Top LED
0.2 sec	7th LED
0.3 sec	6th LED
0.5 sec	5th LED
2.0 sec	4th LED
4.5 sec	3rd LED
6.5 sec	2nd LED
8.5 sec	1st LED

mControl Value for "Preset On"	Corresponding LED Value if done manually
100%	Top LED
99%	Top LED
88%	7th LED
75%	6th LED
62%	5th LED
50%	4th LED
37%	3rd LED
25%	2nd LED
13%	1st LED


Z-Wave Preset On Option



If the Preset On is changed manually, it is recommended that mControl be restarted to ensure that changed values are re-read into mControl's database.

Automation Screen

The Automation Screen allows modifying the configuration of existing or new macros.



Automation Options

The Automation Options buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen
- **Save** – save the changes in the Macro ordering and return to Settings Screen
- **Add Macro** – allows a creation of a new macro on the Add a Macro page


Macro List

This section provides the following configuration options:

- **Macro Enable** – by pressing on this checkbox, the Macro is enabled (with checkmark) or disabled (without checkmark)
- **Macro Edit** – by cursoring to a macro name and pressing OK, access to the Edit Actions Screen is provided
- **Macro Display Order** – by pressing on the UP/DOWN buttons, the display order of the devices for the Macros modified

Add Macro Screen

The Add Macro Screen allows for the creation of a new macro.



Add Macro Options

The Add Macro Options buttons provide the following functions:


- **Back** – goes back to the Automation Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the changes for the current macro and returns to the Automation Screen

This section allows the configuration of the new macro, including:

- **Name** – the name of the macro (Text entry, up to 16 characters)
- **Zone** – the zone in which the macro will show up in the Zone View screen
- **Display in Zone** – enable display of the macro in the selected zone. If this is not enabled, the macro is not displayed in the zone.

Macro Details Screen

Once a macro has been created, use the Macro Detail screen to define it's operation by setting the events or triggers which initiate the macro and setting a list of actions which take place once the macro has been initiated.




Macro Details Options

The Macro Details Options buttons provide the following functions:

- **Back** – goes back to the Automation Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the changes for the current macro and returns to the Automation Screen
- **Add Trigger** or **Add Action** – allows entry of triggers and actions for the macro. This button changes based on the selection of the Macro Triggers or Macro Actions lists.
- **Edit Macro** – goes to the Macro Edit Screen which allow changing information related to the macro

Macro Triggers List

Select the Macro Triggers List to add, enable and change triggers for the macro.



The Macro Trigger Settings provide the following functions:


- **Enable/Disable** – by checking (enabling) or un-checking (disabling) the trigger, will determine if this trigger is considered
- **Trigger Edit** – by cursoring to a trigger name and pressing OK, access to the Edit Trigger Screen to change or delete the trigger.
- **Trigger Order** – by pressing on the UP/DOWN buttons, the order of the trigger



Please note, changing the trigger order has no effect on the “priority” of the trigger. Every trigger has equal priority. This option is provided only to allow organization of which triggers are displayed.

Macro Actions List

Select the Macro Actions List to add, enable and change actions associated with the macro.



The Macro Actions Settings provide the following functions:


- **Enable/Disable** – by checking (enabling) or un-checking (disabling) the action, will determine if this action is executed.
- **Action Edit** – by cursoring to a trigger name and pressing OK, access to the Edit Action Screen to change or delete the action.
- **Action Order** – by pressing on the UP/DOWN buttons, the order of the execution order of the trigger is modified.



Please note, actions are executed in the order set in the list.

Edit Macro Screen

Select the Edit Macro Screen to change macro settings or delete the macro.



The Edit Macro Options buttons provide the following functions:

- **Back** – goes back to the Automation Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the changes for the current macro and returns to the Automation Screen
- **Delete Macro** – deletes the macro

The Edit Macro Settings provide the following functions:

- **Name** – the name of the macro (Text entry, up to 16 characters)
- **Zone** – the zone in which the macro will show up in the Zone View screen
- **Display in Zone** – enable display of the macro in the selected zone. If this is not enabled, the macro is not displayed in the zone.

Macro Triggers

Macros can be triggered by one or more events. Use Macro Triggers to define and enable the events required to trigger a macro.

The following types of events are available to trigger a macro:

Triggers	Meaning
Device	Trigger a macro based on a state change of a device.
IR Event	Trigger a macro based on recognition of a previously learned IR message.
MCE Event	Trigger a macro based on a Media Center event (e.g., DVD play).
One Time	Trigger a macro only once at given time.
Time of Day	Trigger a macro daily at a given time. Optionally, it is possible to select the days of the week the trigger happens and to add a random factor to the trigger time.
Sunrise/Sunset	Trigger a macro upon sunrise/sunset

Device Triggers

Use Device triggers to launch a macro based on a device change. Typical scenarios include:

- Launching a macro based on a motion detection
- Launching a macro based on an INSTEON or Z-Wave paddle press



The Device Trigger options provide the following functions:

- **Device Zone** – the zone the triggering device is located within
- **Device** – the device which will be used for the trigger
- **Command** – the state change to trigger upon
- **Group** – the group which the device trigger belongs to

Device triggers can happen as a result of:

- Internal mControl device changes
 - button presses
 - macro actions.
- External device changes as a result of another device or remote
 - slave linked device changes (INSTEON)
 - remote control operation (INSTEON, Z-Wave and X10)
- External device changes as a result of paddle presses and manual button presses
 - button presses on Z-Wave devices
 - paddle presses on INSTEON and Z-Wave switches

The group field can be used to trigger device macros for multi-buttoned INSTEON devices such as KeyPadLincs and ControlLincs. Select the group based on the position of the button on the device.

The following table describes the mechanism for device triggers:

Device Trigger	Comments
On	<p>Trigger happens when device changes from Off to Preset On or full On.</p> <p><i>Previous Light Value = Off (-1 or 0) → Subsequent Light Value=n, (where n>0)</i></p>
Off	<p>Trigger happens when device changes from Dimmed On, Preset On or Full On to Off.</p> <p><i>Previous Light Value = n, (where n>0) → Subsequent Light Value= Off (-1 or 0)</i></p>



Please note, for “On” Device Triggers, be aware that going to full On (100%) is **NOT** necessary to trigger a macro. Preset On or other non-Off values are sufficient to trigger an “On” Device Trigger.



Device triggers are based on when mControl receives the incoming trigger signal.

- For X10 and INSTEON, there may be a small delay (up to 1 second) for an INSTEON message to travel over the powerline, in to the adapter and be recognized by mControl.
- For Z-Wave, the delay is dependent upon the pre-defined polling rate. For example, if the polling rate is 10 seconds, expect a worst case delay of 10 seconds.



Triggers may be affected (i.e., missed) because of busy network activity and/or amount of messages being handled by the adapter.

- For INSTEON, overlapping messages in/out of the adapter may restrict incoming triggers.
- For Z-Wave, busy network activity may result in lost triggers, due to failed polling attempts.

IR Event Triggers

Use IR Event triggers to launch macro based on recognition of a previously learned IR command. Typical scenarios include:

- Launching a macro based on button press on a remote control



The IR Event options provide the following functions:


- **IR Command** – the IR command to use as a trigger once received.

To trigger using an IR Event, the IR command must first have been learned through the IR Control section of mControl.

MCE Event Triggers

Use MCE Events to trigger macros based on Windows XP Media Center Edition 2005 events changes. Typical scenarios include:

- Launching a macro to dim lights based on the DVD Play button press
- Launching a macro to brighten lights based on muting audio



The MCE Event Trigger fields provide the following functions:

- **Type** – the type of media center functionality which will be used for the trigger
- **Action** – the specific action to be used for the trigger
- **PC Name** – the workstation from which the type/action event is comes from. By leaving this empty, events from all PCs are considered.

The following MCE event options exist:


MCE Event Options	Available Options
Type	<ul style="list-style-type: none">• DVD• CD• Recorded TV• Audio• Video• Live TV
Action	<ul style="list-style-type: none">• Play• Pause• Stop

MCE Events require the “MCE Add-in” to be installed on one or more Windows XP Media Center Edition computers from which Media Center events will originate.

One Time Triggers

Use One Time triggers to run a macro once only. Typical scenarios include:

- Launch a macro for special one-time event




The One Time options provide the following functions:

- **Hour** – the hour when the one time event should be triggered
- **Minute** – the hour when the one time event should be triggered

Time of Day Triggers

Use Time of Day triggers to run macros daily at a given time. Typical scenarios include:

- Launching a macro to shut down outside lights at approximately 11:00pm everyday
- Launch a macro to turn on sprinkler system every Wednesday and Sunday at 6:00am exactly.



The Time of Day Trigger fields provide the following functions:

- **Hour** – the hour when the one time event should be triggered
- **Minute** – the minute when the one time event should be triggered
- **Days of the week** – the days of the week on which the trigger should operate
- **Randomness** – a random factor, shown in minutes, of when the trigger should happen. Use this field to act as a security measure – so that outsiders will not see your triggers acting daily at the exact same time. For example, if you have selected “10” for the Randomness field and 12:15 PM as the trigger hour and minute, the trigger will happen sometime within a window of time between 12:05 PM and 12:25 PM.

Sunrise/Sunset Triggers

Use Sunrise and Sunset triggers to run macros upon sunrise and sunset. Typical scenarios include:

- Turning on outside lights 5 minutes before sunset
- Turning off outside lights 20 minutes before sunrise

Sunrise &
Sunset
Trigger
Options

The Sunrise/Sunset Trigger fields provide the following functions:

- **Offset** – the offset (in minutes) to subtract/add to the time of sunrise/sunset trigger
- **Days of the week** – the days of the week on which the trigger should operate
- **Randomness** – a random factor, shown in minutes, of when the trigger should happen. Use this field to act as a security measure – so that outsiders will not see your triggers acting daily at the exact same time. For example, if you have selected “10” for the Randomness field and sunrise as the trigger mechanism, the trigger will happen sometime within a window of time between 10 minutes before or after sunrise.

Sunrise/sunset triggers are calculated for each day by mControl. The calculation for sunrise/sunset is performed using location settings in the configuration area of mControl. The calculated time including offset will be shown underneath the settings buttons.

mControl uses the Civil (-6° from the horizon) parameters to arrive at sunrise and sunset times, based on the enter location.

To use other calculation methods, navigate to the C:\Program Files\Embedded Automation\mControl\server directory and use a text editor to edit the mServer.exe.config file. Locate the section associated with the "SunRiseZenith" parameter and select an alternate calculation method.

```
<!-- Zenith: Sun's zenith for sunrise/sunset calculations:
      OFFICIAL      = 90 degrees + 50 minutes = -0.8333..
      CIVIL         = 96 degrees   (default if none specified)
      NAUTICAL      = 102 degrees
      ASTRONOMICAL  = 108 degrees -->
<add key="mAuServer.SunRiseZenith" value="CIVIL"/>
```

Also, you may want to use time offsets (and random offsets) to tailor the best sunrise and sunset times for your specific location.

Macro Actions

Macros can consist of one or more actions. Use Macro Actions to define and enable the actions within a macro.

The following types of actions are available for a macro:

Actions	Meaning
Device	Send a command to a device.
Delay	Perform a delay for a given period of time.
IR	Send an IR message.
Macro	Initiate another macro.
Send Mail	Send an email.
Run Application	Launch an application for execution.

For deterministic timing, use the following table to calculate the duration of a macro:

Action Type	Duration of the Macro Action (Before Next Action Starts)
Device	750ms - it may be the case that the command completes in less than or greater than 750ms, but this time is used to add time determinism to mControl macros
Delay	The duration of the delay
All other actions	50ms

Device Actions

Use a Device action to send a command to a device. Typical scenarios include:

- Turn a hallway light on.
- Turn a porch light off.




The Device Action options provide the following functions:

- **Zone** – the zone the triggering device is located within
- **Device** – the device which will be used for the action
- **Command** – the command to send to the device

Delay Actions

Use a Device action to send a command to a device. Typical scenarios include:

- Add a delay between commands, for example, a 15 minute delay between turning a device on and then turning the same device off.




The Delay Action options provide the following functions:

- **Hours** – the amount of hours to delay
- **Minutes** – the amount of minutes to delay
- **Seconds** – the amount of seconds to delay
- **Randomness** – a random factor, measured in minutes, to add to the delay. Use this field to act as a security measure – so that outsiders will not see your actions acting at the exact same time. For example, if you have selected “15” for the Randomness field and 1 hour and 15 minutes as the other fields, then the delay will be in a window between a minimum of 1 hour and 15 minutes and up to 1 hour and 30 minutes.

IR Actions

Use an IR action to send an IR command to a device. Typical scenarios include:

- Send an IR command to a DVD recorder to start recording.



The IR Action options provide the following functions:


- **IR Command** – the IR command that will be sent as part of this action. This command was “Learned” or entered by cutting and pasting raw CCF text in the IR Command section of mControl.
- **IR Device** – the device (or “port”) from which the IR command is to be sent from.
- **Repeat** – the amount of times this action is to be repeated. This may be useful for the case where multiple commands are required, for example, to turn channels on a TV.

Macro Actions

Use a Macro action to initiate another macro. Typical scenarios include:

- Launch a macro which encapsulates frequently used actions, such as turning on or off a set of lights.

Macro
Action
Options



The Macro Action options provide the following functions:

- **Macro** – the macro to initiate.



Please ensure that you do not create “circular” macro loops, that is, the initiating macro is called from within a “sub” or “called” macro.

Send Mail Actions

Use a Send Mail action to send an email. Typical scenarios include:

- Send an email to your cell phone if a motion detector is activated.



The Send Mail Action options provide the following functions:

- **SMTP Server** – use the SMTP mail server address provided by your local ISP or other provider.
- **Email To** – the primary email address to send to.
- **CC To** – the email address which should be CC'ed.

Run Application Actions

Launch an external application, program or batch. Typical scenarios include:

- Initiate a custom application (e.g., backs-up a database).



Please be aware that calling external programs as part of macro actions is a security risk. By using this feature, you can enable the execution of programs at the highest privilege on the computer hosting the mControl Automation Service – including from remote computers using the mControl User Interface Client. By default this feature is disabled and by enabling it the user assumes the risk associated with this functionality.




The Run Application Action options provide the following functions:

- **Application Path** – path of the external application to launch.
- **Parameters** – the command line parameters for the external application.

Camera Screen

The Camera Screen allows modifying the configuration of existing or new cameras.



Automation Options

The Automation Options buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen
- **Add Camera** – allows a configuration of a new camera
- **Camera Media** – allows viewing of recorded camera video/snapshots


Camera List

This section provides the following configuration options:

- **Edit Camera** – by cursoring to a camera name and pressing OK, access to the Edit Camera Screen is provided

Add Camera and Edit Camera Screens

The Add Camera and Edit Camera screens allow for the configuration of a camera.



Edit Camera Options

The Edit an Action Options buttons provide the following functions:

- **Back** – goes back to the Camera Screen
- **Home** – goes back to the Zone View Screen
- **Save** – saves the changes for the current action and returns to the Camera Screen
- **Delete Camera** – deletes the camera and returns to the Camera Screen


Camera Settings

This section provides the following configuration options:

- **Name** – the name of the camera (Text entry, up to 16 characters)
- **Zone** – the location of the camera
- **Camera** – the camera type (refer to the list provided in Supported Hardware)
- **IP Address** – the IP address of the camera. The address can also be in the form of host.domain.com.
- **Port Address** – the http port used by mControl to talk with the camera (usually 80)
- **Username** – username for login
- **Password** – password for login
- **JPG Stream** – select this to retrieve still images (refreshed every 5 seconds) instead of a live video feed. This may be useful for cases where the browser may not handle streaming (or ActiveX) or where performance may be a concern.

Camera Media Screen

The Camera Media screen allows viewing of recorded video and snapshots.



Edit Camera Options

The Edit an Action Options buttons provide the following functions:


- **Back** – goes back to the Camera Screen
- **Home** – goes back to the Zone View Screen
- **Sort by Date** – shows the list of recorded videos and snapshots, sorted by date/time
- **Sort by Name** – shows the list of recorded videos and snapshots, sorted by camera name
- **Sort by Type** – shows the list of recorded videos and snapshots, sorted by media type

Camera Media List

This section provides a list of recorded video and snapshots. View media by cursoring to and selecting an item in the media list.

IR Control Screen

The IR Control screen allows configuration of IR functionality.



IR Control Options

The Automation Options buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen

IR Control Configuration

This section provides the following configuration options:

- **Commands** – add, modify and delete IR commands
- **Adapters** – view available adapter ports. These correspond to the available Global Caché ports available.

Adapters Ports

View the IR ports available for sending commands to.




Adapter Ports

When you select the Adapters tab, this screen provides a list of all the available adapter ports. These ports are used to send and receive IR commands. Use one of these ports in macro actions to define the destination location of the IR command.

mControl currently only display the ports, as configured within the Global Cache or USB UIRT adapters or – you can not edit, delete or add ports.

IR Commands

Shows a list of all IR commands and allows creation of new IR commands.



IR Command Options

The Automation Options buttons provide the following functions:

- **Back** – goes back to the Settings Screen
- **Home** – goes back to the Zone View Screen
- **Add IR Command** – allows creation of a new IR command

IR Commands

This section shows the list of IR commands available for macros.


Advanced mControl Functionality

Using Macros

Device Triggered Macros

Use “Device” triggered macros when you need respond to a status change of a particular device. For example, if a motion detector goes off, you may want to turn on a set of lights for 5 minutes and sound a chime.

1. Create the Macro
 - a. Navigate to the “Settings” page
 - b. Select the “Automation” option
 - c. Select the “Add Macro” option
 - d. Select the “Main” tab and enter the information required to create the macro, including:
 - **Name** – the name of the macro
 - **Zone** – the zone to assign the macro within
 - **Display in Zone** – to enable the display of the macro within the zone
 - e. Select the “Add Trigger” option



2. Select the Triggered Type to be the “Device” trigger, which is the event which will start the macro and then entering the information required, including:
 - **Device Zone** – the zone in which the triggering device is located
 - **Device** – the triggering device (e.g., the motion detector)
 - **Command** – the change to look for to trigger the device
 - **Group** – (optional) the group/key the command will originate from. This group number is required for triggering based on INSTEON SwitchLinc or KeypadLinc buttons (see next section for detailed explanation).

EDIT TRIGGER

Back Home Save Delete Trigger

Triggered Type Device - +

Device Zone INSTEON - +

Device KeypadLinc - +

Command ON - +

Group 3 - +

3. Add an action to take, by selecting the “Add Action” option.


MACRO DETAILS Add More 1 of 2

Back Home Add Action Edit Macro

Device Trigger

Triggers Actions

4. Select the action types to take:



5. Continue steps 3 and 4 until you have defined all the actions required.



Triggering Macros Using INSTEON SwitchLinc or KeypadLinc Buttons

Triggering macros using INSTEON SwitchLinc or KeypadLinc buttons is a type of “device” trigger. Button presses on these devices will generate INSTEON group messages to all the devices linked to it.

First, ensure that the device is created within mControl. This will automatically create a link from the INSTEON PowerLinc adapter (master) to the device (slave).

Second, to allow the INSTEON Adapter to see these button presses, you must “reverse link” the device – in this case, the device (master) is linked to the INSTEON PowerLinc adapter (slave). To do this you must hold down the button on the device and once link mode has been initiated (usually indicated by a flashing light), then hold down the INSTEON PowerLinc's SET button until the device registers the link (again, usually indicated by a flashing light).

Lastly, select the group number associated with button as part of the device trigger option. The following table provides a summary of button/group association:


Device	Button	Group
SwitchLinc Dimmers/Relays 	ON (Load)	Group 1 On
	OFF (Load)	Group 1 Off
KeypadLinc  <i>Factory Setting button settings are provided in this table.</i>	ON (Load)	Group 1 On
	OFF (Load)	Group 1 Off
	A	Group 3 On/Off Toggle
	B	Group 4 On/Off Toggle
	C	Group 5 On/Off Toggle
	D	Group 6 On/Off Toggle

If your KeypadLinc is configured for 8 buttons, instead of 6, you can expand the Group commands available to mControl by adjusting the "GroupTriggersMax" value within module definition for the KeypadLinc within the mServer.exe.xml file located in the C:\Program Files\Embedded Automation\mControl\server directory.

Time Triggered Macros

Use “Time” triggered macros when you need perform home automation functions at a particular time. For example, you may want to turn on lights at 7:00pm and then turn them off at 11:00pm.

1. Create the Macro
 - a. Navigate to the “Settings” page
 - b. Select the “Automation” option
 - c. Select the “Add Macro” option
 - d. Select the “Main” tab and enter the information required to create the macro, including:
 - **Name** – the name of the macro
 - **Zone** – the zone to assign the macro within
 - **Display in Zone** – to enable the display of the macro within the zone
 - e. Select the “Add Trigger” option



2. Select the Triggered Type to be the “Time of Day” trigger, which is the event which will start the macro and then entering the information required, including:
 - **Hour/Minute** – the time when the trigger should happen
 - **Days of the Week** – the days of the week that the trigger can occur
 - **Randomness** – a “random” factor, in minutes, when the trigger should happen

EDIT TRIGGER

Back Home Save Delete Trigger

Triggered Type Time of Day

Hour 5 PM

Minute 45

Monday ☒ Tuesday ☒ Wednesday ☒ Thursday ☒ Friday ☒ Saturday ☐ Sunday ☐

Randomness 10

3. Add an action to take, by selecting the “Add Action” option.


MACRO DETAILS Add More 1 of 2

Back Home Add Action Edit Macro

Device Trigger

Triggers Actions

4. Select the action types to take:



5. Continue steps 3 and 4 until you have defined all the actions required.


MCE Event Triggered Macros

Use “MCE Event” triggered macros when you want to perform home automation functions at a based on how you are using your Windows XP Media Center Edition 2005 system. For example, you may want to automatically dim lights when you start a DVD movie.

Install and configure the MCE Add-in Utility

The MCE Add-in Utility listens and forwards MCE Events to mControl. The MCE Add-in Utility uses Windows XP Media Center Edition 2005's Media State Aggregation Service (MSAS) to retrieve events. Once events are received, the MCE Add-in Utility forwards these events to mControl.


- MCE Add-in Utility must be installed on a MCE machine.
- mControl does not have to be installed an MCE machine.
- The MCE Add-in Utility can be on the same machine as mControl or other machines.
- The MCE Add-in Utility can be installed on multiple machines. Each one of these can be sending messages to mControl.



MCE Add-in on the Same PC as mControl


During mControl installation, the MCE Add-in will be automatically installed if the PC being installed on is a MCE system. In addition, the MCE Add-in will be automatically configured to talk to the mControl on the system.

However, if the system is not a MCE system, the MCE Add-in is not installed.



MCE Add-in on a Different PC then mControl

Use the “MSASAddInSetup.msi” file from your mControl CD or Zip file to install the MCE Add-in Utility on a different PC.



Once installed, you must configure the MCE Add-in Utility to send messages to the mControl machine.

1. Ensure that there is a network between the PC on which the MCE Add-in Utility is installed and the mControl PC. Make a note of the workstation name or IP address of the mControl machine.
2. On the MCE Add-in Utility PC, navigate to the C:\Program Files\Embedded Automation\mControl\mce_addin directory and use a text editor to edit the MSASAddIn.config file. Change the <client> parameters to use the mControl PC's workstation name or IP address instead of "localhost".

The example below shows "localhost" changed to "mcontrol":


```
<client>
  <wellknown type="EmbeddedAutomation.mServerLib.IAuServer, mAuServerLib"
url="tcp://mcontrol:29992/mAuServerURI"/>
  <wellknown type="EmbeddedAutomation.mServerLib.AuServerImpl, mAuServerLib"
url="http://mcontrol:29991/mAuServerURI"/>
</client>
```



Please note, it may be required to reset MCE's Media State Aggregation Service upon changing the configuration information. The simplest way to do this is to reboot.

Create the Macro to Utilize MCE Events


1. Create the macro which will use one or more MCE Events (and other triggers) to run a set of actions.
 - a. Create the Macro
 - i. Navigate to the “Settings” page
 - ii. Select the “Automation” option
 - iii. Select the “Add Macro” option
 - iv. Enter the information required to create the macro, including:
 - **Name** – the name of the macro
 - **Zone** – the zone to assign the macro within
 - **Display** – to enable the display of the macro within the zone
 - v. Save changes




2. Define how the macro will start by adding a “MCE Event” trigger:
 - **Triggered Type** – the type of event to be used in the trigger, for this case, select “MCE Event”
 - **Type** – this is the media type to be triggered on
 - **Action** – this is the media action to be triggered on
 - **PC Name** – the workstation from which the type/action event is comes from. By leaving this empty, events from all PCs are considered.




- Define the set of actions the macro should execute upon receiving the trigger. Use the “Add Action” button to initiate adding a set of actions for this macro.



- The following sample shows a set of actions to take upon receipt of the MCE Event trigger. In this case, mControl will turn off the “Theater – Front” and “Theater – Back” lights.



- The following sample shows a set of actions to take upon receipt of the MCE Event trigger. In this case, mControl will turn off the “Theater – Front” and “Theater – Back” lights.



Using External Programs within Macro Actions



Please be aware that calling external programs as part of macro actions is a security risk. By using this feature, you can enable the execution of programs at the highest privilege on the computer hosting the mControl Automation Service – including from remote computers using the mControl User Interface Client. By default this feature is disabled and by enabling it the user assumes the risk associated with this functionality.

Enable External Program Action Functionality


By default, the ability to call external programs as part of a macro action are disabled. To enable calling of external programs, modify the mAuServer.EnableRunAppAction parameter within the "mServer.exe.config" file, located in the "C:\Program Files\Embedded Automation\mControl\server" directory:

```
<add key="mAuServer.EnableRunAppAction" value="true"/>
```


Enable Interactive Applications (GUI Apps)

If the external application is interactive (i.e. starts a GUI), you must enable desktop functionality.

Navigate to the Windows Service Manager by selecting the Start Button, then Control Panel, the Administrative Tools and finally, Services.




Select “mHome Automation Sever” and then use right-click to access properties for this service. Navigate to the “Log On” tab and select “Allow service to interact with Desktop”. Once enabled, restart the mControl Automation Service (mHome Automation Server).



Example External Application Action


Navigate to the Add Action View and select the Action Type to Run Application:



Type in the full path name of the application in the **Application Path** text box.



In the example, Notepad will launch with the text file C:\test.txt.



Using Security Systems

Supported Security Systems

mControl supports the following security systems:

Security System	Connection Method	Supporting Documentation
Elk M1G	Serial (RS-232), IP Connection	<ul style="list-style-type: none"> Elk M1 – Installation Manual
DSC PowerSeries <i>Platforms: PC1616, PC1832 and PC1864</i>	Serial (RS-232) <i>via DSC PC5401 Module</i>	<ul style="list-style-type: none"> DSC PowerSeries Standard Installation Guide
Honeywell ADEMCO VISTA <i>Platforms: VISTA-128BP and VISTA-250BP</i>	Serial (RS-232) <i>via 4100SM Serial Interface Module</i>	<ul style="list-style-type: none"> ADEMCO VISTA Series – Installation and Setup Guide ADEMCO VISTA Series – Programming Guide

Using Elk Security Systems

- To enable use of the Elk Security System, navigate to the `C:\Program Files\Embedded Automation\mControl\server` directory and use a text editor to edit the `mServer.exe.xml` file. Locate the section associated with the “ELKM1” adapter and make the following changes:
 - To ensure that Elk system driver is loaded, ensure that the load parameter is set to “Y”. This will instruct mControl to load the driver associated with the Elk security system.
 - Select the communication port using the Port parameter. “COM1” is the most common port available. Please confirm that this does not conflict with other drivers or applications.
 - Select the baud rate for the communication port.

```
<adapter base="ELKM1" load="Y" assembly="EA.ELKM1.dll"
driver="EmbeddedAutomation.mServer.Adapters.Elkm1Manager">
...
  <aparam name="Port" value="COM1" />
  <aparam name="BAUD" value="115200" />
...
</adapter>
```



Some computers may not be able to support the default 115,200 baud rate. To adjust to a more suitable baud rate, you will have to make changes both to your Elk system and to the mControl configuration file.


For IP enabled operation, specify the IP address and IP port.

```

<adapter base="ELKM1" load="Y" assembly="EA.ELKM1.dll"
driver="EmbeddedAutomation.mServer.Adapters.Elkm1Manager">
...
    <aparam name="IPAddress" value="192.168.1.99"/>
    <aparam name="IPPort" value="2101"/>
...
</adapter>

```

2. Within the Edit Device page, add the Elk M1G security system.



Configure the following Elk Device Options.

- **Name** – the name of the Elk area. A different device can be added for each area.
- **Adapter** – select “ELKM1-ELKM1”
- **Area** – select an area – this corresponds to the (partitioned) areas for the Elk M1.


Once an ELKM1 device has been added, it can be viewed within the main View Zone page as a device.

Using Digital System Control (DSC) PowerSeries Security Systems

1. To enable use of the DSC PowerSeries Security System, navigate to the C:\Program Files\Embedded Automation\mControl\server directory and use a text editor to edit the mServer.exe.xml file. Locate the section associated with the "DCSPS" adapter and make the following changes:
 - To ensure that DSC PowerSeries system driver is loaded, ensure that the load parameter is set to "Y". This will instruct mControl to load the driver associated with the DSC PowerSeries security system.
 - Select the communication port using the Port parameter. "COM1" is the most common port available. Please confirm that this does not conflict with other drivers or applications.
 - Select the baud rate for the communication port.

```
<adapter base="DSCPS" load="Y" assembly="EA.DSCPS.dll"
  driver="EmbeddedAutomation.mServer.Adapters.DscManager">
  <aparam name="DISPLAY-AS" value="DSC PS" />
  <aparam name="Description" value="DSC PowerSeries Security
    System" />
  <aparam name="Supports" value="DSCPS" />
  <aparam name="AProtocol" value="DSCPS" />
  <aparam name="FirstInternalDeviceId" value="-2" />
  <aparam name="DebugLevel" value="5" />
  <aparam name="COMPort" value="COM1" />
  <aparam name="BAUD" value="9600" />
  <aparam name="KeepPortOpen" value="true" />
  <aparam name="ResponseTimeout" value="2000" note="value in
    milliseconds" />
</adapter>
```

2. Within the Edit Device page, add the DSC PowerSeries security system.



Configure the following DSC Device Options.

- **Name** – the name of the DSC area. A different device can be added for each area.
- **Adapter** – select “DSCPS-DSCPS”
- **Area** – select an area – this corresponds to partitioned areas for the DSC PowerSeries.

Once a DSC device has been added, it can be viewed within the main View Zone page as a device.

Using Honeywell ADEMCO VISTA Security Systems

1. To enable use of the Ademco Vista Security System, navigate to the `C:\Program Files\Embedded Automation\mControl\server` directory and use a text editor to edit the `mServer.exe.xml` file. Locate the section associated with the “Ademco” adapter and make the following changes:
 - To ensure that Ademco system driver is loaded, ensure that the load parameter is set to “Y”. This will instruct mControl to load the driver associated with the Ademco Vista security system.
 - Select the communication port using the Port parameter. “COM1” is the most common port available. Please confirm that this does not conflict with other drivers or applications.
 - Select the baud rate for the communication port.

```
<adapter base="ADEMCO" load="Y" assembly="EA.Ademco.dll"
driver="EmbeddedAutomation.mServer.Adapters.AdemcoManager">
  <aparam name="DISPLAY-AS" value="Ademco"/>
  <aparam name="Description" value="Honeywell Ademco Vista Security
    System"/>
  <aparam name="Supports" value="VISTA"/>
  <aparam name="AProtocol" value="VISTA"/>
  <aparam name="DebugLevel" value="5"/>
  <aparam name="COMPort" value="COM1"/>
  <aparam name="BAUD" value="1200"/>
  <aparam name="KeepPortOpen" value="true"/>
  <aparam name="ResponseTimeout" value="2000" note="value in
    milliseconds"/>
</adapter>
```

2. Within the Edit Device page, select the ELKM1 device.







Configure the following Ademco Vista Device Options.

- **Name** – the name of the Ademco Vista area. A different device can be added for each area.
- **Adapter** – select “ADEMCO-VISTA”
- **Area** – select an area – this corresponds to partitioned areas for the Ademco Vista.

Once an Ademco Vista device has been added, it can be viewed within the main View Zone page as a device.

Understanding Security Systems Status

Current Settings Parameter	Graphic	Description
Ready status		System is not ready to be armed. Typically related to zone violations.
		System is ready to be armed.
Armed status		System is not armed.
		System is armed


Changing Security Systems Settings

To view detailed settings or to change settings, select the “Play” button on the device to access the Security View screen.



Security View Screen Overview

The Security View screen allows you to view the current status of the security system, arm/disarm the system and view zone statuses.




Security View Options

The Security View Options buttons provide the following functions:

- **Back** – goes back to the Zone View Screen
- **Apply** – applies the selected Security Mode settings

Security View Main Tab

Use the Main tab to view the current status of the system and to arm and disarm the system.



Status Information – the current status of the security system for the area indicated.

Keypad – numeric keypad to allow touch screen operation. Use the “X” key to clear the PIN Code field.

Arm/Disarm Function – select the Security Mode, enter the PIN # and press apply to change the current status of the Elk system. The following Security Modes are available:

Security Mode	Description
Disarmed	System is disarmed.
Armed Away	Away mode arming is the highest arm level, intended for use when the premise is unoccupied. Both perimeter and interior zones will be armed.
Armed Stay, Armed Stay Instant, Armed to Night, Armed to Night Instant	The various stay arming modes are intended for use when the premise is occupied. All perimeter doors and windows are armed, and all interior zones are excluded.
Armed to Vacation	Vacation mode is a second level of Away mode. It can be used to activate energy saving automation features when the building will not be occupied for an extended period of time.


For more information on Security Modes, please refer to the security system's user manual.



For Ademco Vista systems, the PIN Code will need to be prefixed with the last two digits of the user code. For example if the user code is “002” and the PIN Code is “1234”, the entry within the PIN Code field will need to be “021234”.

Security Zones Tab

Use the Security Zones tab to view the current status of the zones defined in the system.



Zone Status Information – the current status each zone defined within the area is shown.

Triggering Macros using Security System Events

Security system events can be used to trigger mControl macros. To do this, add an mControl macro trigger, select the “Device” Action Type and reference the security system event to be used for the trigger.

The following events are available as triggers:

- **Armed** – when a security system is armed
- **Disarmed** – when a security system is disarmed
- **Burglar Alarm** – when a burglar alarm is raised
- **Other Alarm** – when a (non-burglar) alarm is raised

ADD TRIGGER

Back Home Save

Triggered Type Device - +

Device Zone Security - +

Device Vista Area 1 - +

Command Burglar Alarm - +

Using Irrigation Controllers

Irrigation Controllers

mControl supports the following irrigation controllers:

Irrigation Controllers	Connection Method	Comments
EZRain V1	INSTEON protocol	Please refer to the EZRain V1 data sheet for additional information.

EZ Rain V1 Irrigation Controllers

Add an EZRain Irrigation Controller to mControl


Within the Edit Device page, select the EZRAIN device.



From the Main tab area configure the following EZRain Device Options.

- **Name** – the name of the EZRain irrigation controller
- **Adapter** – the INSTEON adapter to use to communicate with the EZRain irrigation controller
- **INSTEON Address** – the INSTEON address of the EZRain irrigation controller
- **Image** – the image to use with this EZRain irrigation controller

By selecting the Advanced tab, additional configuration items can be set.




Configure the following EZRain Advanced Device Options.




- **Valve 8 Mode** – use this setting to determine how valve 8 will be used. The following modes are available:

Valve 8 Mode	Description
Normal	Valve 8 operates the same as all other valves.
Pump	Valve 8 is turned ON when another valve is ON. This allows the valve 8 to enable a pump that may be used in conjunction with the other valves.

Once an EZRain device has been added, it can be viewed within the main View Zone page as a device.




Each EZRain device will provide the following status indicators:

Indicator	Active (ON)	Inactive
Valve 1-8		
Program 1-4	 Active program is shown	No program image is shown

To view detailed settings or to change settings, select the “Play” button on the device to access the EZRain View screen. The EZRain View screen allows you to view the detailed current status of the security system and make changes to these settings.

Changing or Viewing EZRain Settings

Use the EZRain View page to get the current status of the EZRain device, manually control valves, create program settings and manually run programs.




From the EZView View use the following tabs to view, configure and control the following EZRain Device Options.

- **Main** – view the current status of the EZRain device
- **Manual** – manually control the EZRain device
- **Prog 1 ... Prog 4** – configure and launch EZRain programs

Main Tab

Use the Main tab to view the current status of your EZRain device.



The following EZRain View Main Options are available:


- **Back** – return to the View Zone page

The following real-time status information is provided:

- **Valves** – status of each valve
- **Programs** – status of programs
- **Valve 8 Mode** – the type of mode for Valve 8

Manual Tab

Use the Manual tab to view the current status of your EZRain device.



The following EZRain View Manual Options are available:


- **Back** – return to the View Zone page
- **Apply** – commit the entered Valve Schedule settings to the EZRain Irrigation Controller

The following EZRain View Manual Settings are available:

- **Valve Schedule** – the time in minutes for each valve to operate
- **Valve** – the valve to operate
- **Run/Stop** – manual control of the Valve specified

Program Tab

Use the Program tab to view the current status of your EZRain device.



The following EZRain View Program Options are available:

- **Back** – return to the View Zone page
- **Apply** – commit the entered Valve Schedule settings for the selected Program to the EZRain Irrigation Controller
- **Start/Stop Program** – initiate or stop the selected Program

The following EZRain View Program Settings are available:

- **Valve Schedule** – the time in minutes for each valve to operate for the selected Program

Using Thermostats

Using HAI Thermostats

1. To enable HAI thermostat support within mControl, edit mControl configuration settings in the "mServer.exe.xml" located in the C:\Program Files\Embedded Automation\mControl\server directory.

Open the "mServer.exe.xml" file using Notepad or equivalent text editor, find the section which has configuration settings for the HAI thermostat and make the following highlighted changes to load the HAI thermostat driver into mControl – ensure that the load parameter for the adapter is "Y" and the parameters for COM port and baud rate are correct:

```
<adapter base="HAIRC" load="Y" assembly="EA.HAIRC.THERMO.dll"
  driver="EmbeddedAutomation.mServer.Adapters.HaiRcsThermoManager">
  <aparam name="DISPLAY-AS" value="HAI RC Thermo" />
  <aparam name="Description" value="HAI RC-Serial Thermostat" />
  <aparam name="Supports" value="HAIRC" />
  <aparam name="AProtocol" value="HAIRC" />
  <aparam name="DebugLevel" value="9" />
  <aparam name="COMPort" value="COM1" persistent="false" />
  <aparam name="BAUD" value="300" persistent="false" />
  <aparam name="KeepPortOpen" value="true" />
  <aparam name="ResponseTimeout" value="1250" note="value in
    milliseconds" />
</adapter>
```



Please ensure that the selected COM port does not conflict with other adapters using the same port and within the mServer.exe.xml file. To enable any changes in adapter XML settings, you must restart the mControl Automation Service, which during initialization reads the XML files.

2. Add the HAI Thermostat using the Add/Edit Device page.
 - **Name** – Provide a name for the thermostat
 - **Adapter** – Select "HAIRC-HAIRC" to select HAI Omnistat RC series thermostat
 - **Module** – By default, the module will be "HAIRC.THERMO"
 - **RC Address** – Specify the address of the HAI Omnistat RC series thermostat. Refer to the HAI Omnistat RC thermostat manual to determine addressing for your thermostat – mControl does not have any limit on the amount of thermostats allowed.



3. Once the thermostat device is saved, current settings will be read from the HVAC control unit. This process can take several seconds.



Using RCS Thermostats

mControl supports two versions of RCS thermostats:

Thermostat Module	Required Adapter	Comments
TXB16 (X10)	CM11A X10 Adapter or 2414U INSTEON Adapter	Only these adapters have sufficient functionality to send/receive commands to/from the TXB16 thermostat. An X10 House code must also be selected. Please refer to the TXB16 Thermostat User Manual for detailed instructions.
ZWThermo for TZ16 and other Z-Wave compatible thermostats	Z-Wave Adapters	Generic Z-Wave adapter can be selected. If the thermostat device is not already within the adapter, you may have to enroll it. For more information on enrollment, please refer to the Z-Wave section of this manual. Please refer to the TZ16 Thermostat and/or other Z-Wave thermostat User Manual for detailed instructions

Using RCS TXB16 Thermostats

1. To enable RCS TXB16 thermostat support within mControl, edit mControl configuration settings in the "mServer.exe.xml" located in the C:\Program Files\Embedded Automation\mControl\server directory.

For RCS TXB16 thermostats, ensure that either the CM11A X10 Adapter or the 2414U INSTEON Adapter are enabled.

Open the "mServer.exe.xml" file using Notepad or equivalent text editor, find the section which has configuration settings for the either the CM11A or 2414A adapters and make the following highlighted changes to load the adapter into mControl – ensure that the load parameter for the adapter is "Y" and the parameters for COM port are correct:

```
<adapter base="CM11A" load="Y" assembly="EA.InsteonX10.dll"
  driver="EmbeddedAutomation.mServer.Adapters.CM11AManager">
  <aparam name="DISPLAY-AS" value="CM11A" />
  <aparam name="Description" value="ActiveHome X10 Serial Adapter" />
  <aparam name="Supports" value="X10|X10PDIM|X10EXT" />
  <aparam name="AProtocol" value="X10" />
  <aparam name="Port" value="COM1" persistent="false" />
  <aparam name="KeepPortOpen" value="true" />
  <aparam name="ResponseTimeout" value="2500" />
  <aparam name="X10ThermoRqWait" value="3500" />
  <aparam name="DebugLevel" value="5" />
</adapter>
```



To enable any changes in adapter XML settings, you must restart the mControl Automation Service, which during initialization reads the XML files.

2. Add the RCS TXB16 thermostat using the Add/Edit Device page.
 - **Name** – Provide a name for the thermostat
 - **Adapter** – Select “CM11A-X10” or “2414X-INSTEON” adapter
 - **Module** – Select “TXB16”
 - **House** – Specify the X10 house address for the RCS TXB16 thermostat



Embedded Automation recommends the CM11A X10 adapter for use with RCS TXB16 (X10).

For the TXB16 (X10), once the house code has been selected, no other devices should use that house code to ensure proper communication between mControl and the thermostat.

3. Once the thermostat device is saved, current settings will be read from the HVAC control unit. This process can take minutes.

Using RCS TZ16 Thermostats

1. To enable RCS TZ16 thermostat support within mControl, edit mControl configuration settings in the "mServer.exe.xml" located in the C:\Program Files\Embedded Automation\mControl\server directory.

Open the "mServer.exe.xml" file using Notepad or equivalent text editor, find the section which has configuration settings for the Z-Wave adapter and make the following highlighted changes to load the adapter into mControl – ensure that the load parameter for the adapter is "Y":

```
<adapter base="ZWCTRL" load="Y" assembly="EA.ZWAVE.dll"
  driver="EmbeddedAutomation.mServer.Adapters.ZWaveManager">
    <aparam name="DISPLAY-AS" value="Z-Wave Controller" />
    <aparam name="Description" value="Z-Wave USB Controller" />
    <aparam name="Supports" value="ZWAVE" />
    <aparam name="AProtocol" value="ZWAVE" />
    <aparam name="Port" value="USB" persistent="false" />
    <aparam name="DebugLevel" value="5" />
    <aparam name="PollingSeconds" value="10" note="zero means no
      polling. Allowed range: {0-3600} sec. default=10" />
  </adapter>
```













To enable any changes in adapter XML settings, you must restart the mControl Automation Service, which during initialization reads the XML files.

2. Add the RCS TZ16 thermostat using the Add/Edit Device page.
 - **Name** – Provide a name for the thermostat
 - **Adapter** – Select "ZWCTRL-ZWAVE" adapter
 - **Module** – Will default to "ZWave Thermostat"
 - **Z-Wave ID** – the selected Z-Wave ID for the RCS TZ16 thermosta


3. Once the thermostat device is saved, current settings will be read from the HVAC control unit. This process can take minutes. For Z-Wave thermostats, the rate at which the data from the thermostat is read will depend on the Z-Wave polling settings.

Understanding Thermostat Status

Current Settings Parameter	Graphic	Description
Current temperature		Current temperature value in C or F.
Current mode of operation		For X10 thermostats, this icon will be shown in Automatic mode For Z-Wave thermostats, the icon representing the actual mode of operation will be shown: Heat, Cool or Off.
		Heat mode For Z-Wave thermostats, if the thermostat is in Auto mode, but currently heating, this icon will be shown
		Cool mode For Z-Wave thermostats, if the thermostat is in Auto mode, but currently cooling, this icon will be shown
		Off mode For Z-Wave thermostats, if the thermostat is in Auto mode, but currently idle, this icon will be shown
Current fan setting		For X10 thermostats, this icon will be shown if the fan is in Automatic mode For Z-Wave thermostats, the icon representing the actual mode of fan operation will be shown: On or Auto.
		Fan ON mode For Z-Wave thermostats, if the fan is in Auto mode, and currently On, this mode will be shown
		Fan OFF For Z-Wave thermostats, if the fan is in Auto mode, but currently idle, this mode will be shown
Current Set Points	 XX	For Cool or Auto mode, cooling begins 1 degree above this temperature
	 XX	For Heat or Auto mode, heating begins 1 degree below this temperature

Changing Thermostat Settings

To view detailed settings or to change settings, select the “Play” button on the device to access the HVAC View screen.



The HVAC View screen allows you to view the detailed current settings of the thermostat device and make changes to these settings.



Current HVAC Settings are based on the real-time status of the thermostat.

Editable HVAC Settings:

- **Mode** – mode of operation for the thermostat
- **Fan** – mode of operation for the fan
- **Setpoints** – heat or cool set points



Changes to the Editable HVAC Settings will only be applied after pressing the “Apply” button. Changes can take several seconds to be applied within the HVAC Control Unit and up to several minutes to update on the device.

Adjusting HVAC Settings in Macros

Thermostat settings can be adjusted within mControl macros. To do this, add an mControl macro action, select the “Device” Action Type and reference the thermostat to be adjusted. Select the parameters to be applied once the action is executed.




The screenshot shows the 'ADD ACTION' screen in the mControl interface. On the left, there are three buttons: 'Back', 'Home', and 'Save'. The main area is divided into two columns. The left column lists the parameters to be configured: 'Action Type', 'Zone', 'Device', 'Mode', and 'Fan'. The right column shows the selected values for each parameter, with minus and plus buttons for adjustment. The 'Action Type' is set to 'Device'. The 'Zone' is set to 'Main Floor'. The 'Device' is set to 'Main Thermo'. The 'Mode' is set to 'Cool'. The 'Fan' is set to 'Auto'. At the bottom, the 'Cooling' temperature is set to 26, with up and down arrow buttons for adjustment.

Parameter	Value
Action Type	Device
Zone	Main Floor
Device	Main Thermo
Mode	Cool
Fan	Auto
Cooling	26

Using Cameras

Using Axis Cameras


1. Follow the instructions provided with your Axis camera to complete the hardware set-up, including establishing the wired or wireless network and connecting power.
2. Use the Axis IP Utility to find the available cameras. **Please note the IP Address here for future use – mControl requires this information.**



3. Double-click to access the camera.



Upon entering this screen for the first time, the Axis software automatically loads a MPEG4 ActiveX component which allows you to view the camera. This procedure must be followed to load the ActiveX object on each client machine you wish to view the camera.



4. Navigate to the “Setup” section, then select the “User” option. For security reasons, you may create an mControl user by assigning a Username/Password. **Please note the Username/Password here for future use – mControl requires this information.**

AXIS 211A Network Camera Live View | Setup | Help

Basic Configuration

- Instructions
- 1. Users
- 2. TCP/IP
- 3. Date & Time
- 4. Video & Image
- 5. Focus
- 6. Audio

Video & Image

Audio

Live View Config

Event Configuration

System Options

About

Users

User List

User Name	User Group
root	Administrator

Add... Modify... Remove

User Settings

☒ Enable anonymous viewer login (no user name or password required)

Maximum number of simultaneous viewers limited to: 20 [0..20]

Subsequent viewers will see a blank image.

Save Reset


5. Once completed, you may have to re-power (or reset) your camera.
6. Now you are ready to add the camera to mControl software.
- Navigate to the “Settings” page
 - Select the “Camera” option
 - Select the “Add Camera” option
 - Enter the information required to connect to the camera, including:
 - Name** – the name of the camera (for example, “Back Porch”)
 - Zone** – the zone that the camera should be displayed within
 - Model** – the camera model
 - IP Address** – as per step #2 of this process, enter the IP or host.domain.com address.
 - Port** – HTTP port number assigned for the camera
 - Username** – as per step #4, enter the Username
 - Password** – as per step #4, enter the Password
 - “Save Changes” and return




ADD CAMERA

Back	Name	Office	
Home	Zone	Media Center	- +
Save	Module	AXIS 21x	- +
Delete Camera	IP Address	10.100.100.90	
	Port	80	
	Username	root	
	Password	••••	

7. View the camera from the “Zone View” screen





8. Navigate to the “Play” button on the camera device. If you press OK, a full-screen will be displayed.



Using Panasonic Cameras

1. Follow the instructions provided with your Panasonic camera to complete the hardware set-up, including establishing the wired or wireless network and connecting power.
2. Access the Panasonic camera and use the “Setup” tab to configure the network settings.
Please note the IP Address for future use – mControl requires this information.



3. Navigate to the “Administrator” section under the “Setup” tab. For security reasons, you may create an mControl user by assigning a Username/Password. **Please note the Username/Password here for future use – mControl requires this information.**


4. Once completed, you may have to re-power (or reset) your camera.

5. Now you are ready to add the camera to mControl software.
 - a. Navigate to the "Settings" page
 - b. Select the "Camera" option
 - c. Select the "Add Camera" option
 - d. Enter the information required to connect to the camera, including:
 - **Name** – the name of the camera (for example, "Back Porch")
 - **Zone** – the zone that the camera should be displayed within
 - **Model** – the camera model
 - **IP Address** – as per step #2 of this process, enter the IP or host.domain.com address.
 - **Port** – HTTP port number assigned for the camera
 - **Username** – as per step #3, enter the Username
 - **Password** – as per step #3, enter the Password
 - e. "Save Changes" and return


EDIT CAMERA

Back	Name	Backyard
Home	Zone	Security - +
Save	Camera	PANACAM - +
Delete Camera	IP Address	10.100.100.91
	Port	80
	Username	embedded
	Password


6. View the camera from the “Zone View” screen. On the initial view, you may be asked for user name and password.



The camera will be displayed as a device.



7. Navigate to the “Play” button on the camera device. If you press OK, a full-screen will be displayed.



Using D-Link Cameras

1. Follow the instructions provided with your D-Link camera to complete the hardware set-up, including establishing the wired or wireless network and connecting power.
2. Use the D-Link software's IP Installer option to find the available cameras. Click on the "Link" button to configure for mControl. **Please note the IP Address here for future use – mControl requires this information.**



- Once linked, select the “Configuration” option of the camera.




Once you enter this screen, the D-Link software automatically loads a MPEG4 ActiveX component which allows you to view the camera. This procedure must be followed to load the ActiveX object on each client machine you wish to view the camera.




- Navigate to the “Tools” tab, then select the “Admin” option. For security reasons, you may create an mControl user by assigning a Username/Password. **Please note the Username/Password here for future use – mControl requires this information.**




5. Once completed, you will either have to re-power (or reset) your camera.
6. Now you are ready to add the camera to mControl software.
 - f. Navigate to the “Settings” page
 - g. Select the “Camera” option
 - h. Select the “Add Camera” option
 - i. Enter the information required to connect to the camera, including:
 - **Name** – the name of the camera (for example, “Back Porch”)
 - **Zone** – the zone that the camera should be displayed within
 - **Model** – the camera model
 - **IP Address** – as per step #2 of this process, enter the IP or host.domain.com address
 - **Port** – HTTP port number assigned for the camera
 - **Username** – as per step #4, enter the Username
 - **Password** – as per step #4, enter the Password
 - j. “Save Changes” and return



7. View the camera from the “Zone View” screen



8. Navigate to the “Play” button on the camera device. If you press OK, a full-screen will be displayed.



Adding a Custom Camera

If you do not see your camera supported within mControl's supported list of Security Cameras, it may still be possible to use the camera. Use the following procedure to add a custom camera:

1. Add the custom camera definition to the mServer.exe.xml file located in the C:\Program Files\Embedded Automation\mControl\server directory.



This process is recommended for users familiar with software coding. Please be aware that adding erroneous information to this file may cause failure of mControl to properly start and operate. It is recommended to make a back-up copy of this file before you make changes. Also, this procedure requires knowledge of the custom camera's (ActiveX) objects and parameters.

Add a new section within the <modules> section and make the changes recommended in the table below. (It is recommended that you use the "Axis 21x" base as a starting point.)

```
<module base="AXIS 21x">
  <mparam name="CLASS" value="CAMERA"/>
  <mparam name="DISPLAY-AS" value="AXIS 210/211"/>
  <mparam name="Description" value="AXIX 21x Series Internet Camera"/>
  <mparam name="MProtocol" value="AXIS"/>
  <mparam name="DefaultImage" value="Camera.gif"/>
  <mparam name="CLASSID" value="745395c8-d0e1-4227-8586-624ca9a10a8d"/>
  <mparam name="CODEBASE"
value="http://{0}:{1}/activex/AMC.cab#version=3,32,14,0"/>
  <object-params>
    <param name="MediaURL" value="http://{0}:{1}/axis-
cgi/mjpg/video.cgi"/>
    <param name="MediaType" value="mjpeg-unicast"/>
    <param name="MediaUsername" value="{2}"/>
    <param name="MediaPassword" value="{3}"/>
    <param name="AutoStart" value="1"/>
    <param name="UIMode" value="none"/>
    <param name="EnableReconnect" value="1"/>
    <param name="StretchToFit" value="1"/>
    <param name="NetworkTimeout" value="5000"/>
    <param name="ShowStatusBar" value="1"/>
  </object-params>
</module>
```

Make the following changes to the parameters associated with the new <module>:


Element	Name	Value	Description
module	base	string value	Name of the camera type
mparam	CLASS	"CAMERA"	Used by mControl to designate camera device
mparam	DISPLAY-AS	string value	String to show in camera selection page
mparam	Description	string value	Long description of camera
mparam	MProtocol	string value	Protocol associated with the camera
mparam	DefaultImage	string value	Image to associate with the camera
mparam	CLASSID	string value	GUID of the object
mparam	CODEBASE	string value	Location of code for object
param	Depends on object – please refer to the technical documentation associated with the camera's (ActiveX) object

It is also possible to add parameters which are based on values stored within mControl. Use the following nomenclature to add stored values within mControl to the module:


Parameter	Substituted Value Loaded at Run-time (from the mControl database for the camera device)
{0}	IP Address
{1}	HTTP Port Number
{2}	Username
{3}	Password

Using Advanced Camera Functionality from the Camera View page

The Camera View page is accessible by pressing the “play” button on any camera device from the main View Zone page.



The Camera View page will display a full-size live image from the camera and based on the capabilities of the camera, will provide access to advanced camera functionality.



Camera View Options

The Camera View buttons provide the following functions:

- **Back** – goes back to the View Zone screen
- **Take Snapshot** – takes a snapshot of the live image. The snapshot is available for viewing in the Camera Media page.
- **Start Recording** – records a video of the live image. The recorded video is available for viewing in the Camera Media page. This will record 60 seconds of video at 2 frames per second. This video will be available a couple of minutes after the button is pressed.

Pan-Tilt-Zoom Options

If panning, tilting and zooming is supported by the camera, buttons will be available to allow for this control.

Using Camera Devices within Macros

Cameras may be used within mControl macros in the following ways:

- Using the camera's native motion sensing capabilities, upon motion detection, trigger an mControl macro.
- As an action within an mControl macro, record a video from the camera
- As an action within an mControl macro, take a snapshot from the camera

Triggering Macros based on Camera Motion Detection


To trigger a macro based on a camera's native motion sensing capabilities, the camera must first be configured to send a "motion" event to mControl. Once the camera is configured, use mControl's automation functionality to trigger macros based on the camera's motion event.




Currently, this functionality is only supported through Axis cameras.

The following set up procedure will configure the camera to send a motion event to mControl:

1. Navigate to the camera's IP address to start configuration



- Navigate to the “Setup” section and then select “Event Configuration”.




- Select the “Event Server” option within the “Event Configuration” section to set the server to which the event will be sent to.




Select the “Add TCP ...” tab to add a TCP event. The following parameters are required:

- TCP Server Name:** mServerTcpListner
- Network Address:** IP address of the PC running the mControl Automation Service
- Port:** 29993 (or the port set within the mServer.exe.config file)




4. Select the “Event Types” option within the “Event Configuration” section to configure the motion detection event.




Select the “Add triggered ...” tab to add a motion triggered event. The following parameters are required:


- **Name:** Provide a name for the event
- **Priority:** Normal
- **Respond to Trigger:** Select when the trigger should happen
- **Triggered by:** Select how the trigger should happen
- **When Triggered:**
 - “Send TCP notification to” field must be checked and set to “mServerTcpListner”
 - “Message” field must be filled in with either: “MESSAGE_CAMERA|MOTION START” (if you selected a trigger when motion detection starts) or “MESSAGE_CAMERA|MOTION STOP” (if you selected a trigger when motion detection stops)



5. Select the “Motion Detection” option within the “Event Configuration” section to configure the sensitivity and windows to be used for the motion detection event.



6. Since the camera is now configured to send motion events, it is now possible to add a macro trigger to mControl to act upon this motion event. Create a macro and related trigger.



Recording Videos as a Macro Action

Please note that videos can take a significant amount of disk space and CPU effort.

The size of the video is dependent on the duration (in seconds) of the video, the amount of frames per second for the video and the size of the camera image (320x240).

Once mControl records the incoming video stream, the video converts is then converted AVI format. This conversion process can take a significant amount of CPU effort. The CPU effort is related to the size of the video file being converted.

Embedded Automation recommends the following for generating videos within macros:

- **Ensure that you have set aside adequate disk space set aside for video recording.**
- **Record only what is necessary. Ensure that video recording macros do not launch unnecessarily.**
- **Manage recorded videos by deleting videos that are no longer required.**

To record videos within an mControl macro action, create a macro and add an action with the following parameters:

- **Action Type:** Device
- **Zone:** Zone in which the camera is located
- **Device:** Camera to record from
- **Command:** Select "Record Video" to record video
- **Duration:** Length of the video to record (in seconds)
- **Frames/Second:** Frame rate for the video. While mControl will attempt to record at this frame rate this will also depend on camera's capability, network bandwidth and CPU performance. To control disk space use, remember lower frame rates will make for smaller files.



Recorded video is stored in the directory defined within the mControl.exe.xml file:

```
<adapter base="IPCAMDRV" load="Y" assembly="EA.Cameras.dll"
  driver="EmbeddedAutomation.mServer.Adapters.IpCamsManager">
  <aparam name="Description" value="IP Cameras Driver" />
  <aparam name="RelativeSavePath" value="..\..\mControl\CamStore" />
</adapter>
```

To view recorded video, navigate to the Camera Media page:



Taking Snapshots as a Macro Action

To take snapshots within an mControl macro action, create a macro and add an action with the following parameters:

- **Action Type:** Device
- **Zone:** Zone in which the camera is located
- **Device:** Camera to record from
- **Command:** Select "Take Snapshot" to take a snapshot
- **# of Snapshots:** How many snapshots to take
- **Interval:** The amount of time (in seconds) between each snapshot



Snapshots are stored in the directory defined within the mControl.exe.xml file:

```
<adapter base="IPCAMDRV" load="Y" assembly="EA.Cameras.dll"
  driver="EmbeddedAutomation.mServer.Adapters.IpCamsManager">
  <aparam name="Description" value="IP Cameras Driver" />
  <aparam name="RelativeSavePath" value="..\..\mControl\CamStore" />
</adapter>
```

To view snapshots, navigate to the Camera Media page:




Viewing Recorded Videos and Snapshots within Windows Media Center

If you are using Windows XP Media Center, it is possible to view video and snapshots using Media Center's native video and picture viewing system.

1. Access the "My Videos" or "My Pictures" section of Media Center




2. Use the Info button on your remote to "Add Pictures".



3. Select the folder where videos and snapshots are being stored to. By default, this folder is located in the C:\Program Files\Embedded Automation\mControl\CamStore directory.




4. Once the folder is added, the videos or snapshots will be available from within Media Center.




Using IR Commands

Configuring Global Caché for Use with mControl

1. Follow the instructions provided with your Global Caché Network IR Adapter to complete the hardware set-up, including establishing the wired or wireless network and connecting power.
2. Connect to the GC-100 Network Adapter using the default IP address and configure the IP Address, Network Mask and Gateway Address to be compatible for your network.



You may also want to configure the Port settings for each of the ports available on the GC-100 Network Adapter – mControl use these settings to send and receive IR commands.



3. Enable and configure the GC-100 Network Adapter within mControl, by editing the configuration settings in the “mServer.exe.xml” located in the C:\Program Files\Embedded Automation\mControl\server directory.

Open the “mServer.exe.xml” file using Notepad or equivalent text editor, find the section which has configuration settings for the GC-100 Network Adapter and make the following changes:


- Load the GC-100 Network Adapter driver into mControl – ensure that the load parameter for the adapter is “Y” (see underlined section below).
- Provide the proper IP Address for the GC-100 Network Adapter – ensure the value of the IP parameter matches the IP Address entered during step #2 (see underlined section below).

```
<adapter base="GC100" load="Y" assembly="GC100.dll"
driver="EmbeddedAutomation.mServer.Adapters.GC100Manager">
  <aparam name="DISPLAY-AS" value="GC-100"/>
  <aparam name="OTHER-NAMES" value="GC-100-12|GC-100-18"/>
  <aparam name="DESCRIPTION" value="GlobalCache Network Adapter"/>
  <aparam name="SUPPORTS" value="GC100"/>
  <aparam name="APROTOCOL" value="GC100"/>
  <aparam name="PORTS" value="4998"/>
  <aparam name="ip" value="192.168.100.71" />
</adapter>
```




To enable any changes in adapter XML settings, you must restart the mControl Automation Service, which during initialization reads the XML files.

4. Once successfully configured, the various available ports will be visible on the IR Command page, under the Adapters section.



Configuring USB UIRT for Use with mControl

1. Attach the USB UIRT to a free USB port. Install the provided drivers by selecting the



2. Enable and configure the USB UIRT within mControl, by editing the configuration settings in the "mServer.exe.xml" located in the C:\Program Files\Embedded Automation\mControl\server directory.

Open the "mServer.exe.xml" file using Notepad or equivalent text editor, find the section which has configuration settings for the USB UIRT and make the following changes:

- Load the USB UIRT driver into mControl – ensure that the load parameter for the adapter is "Y" (see underlined section below).

```
<adapter base="UUIRT" load="Y" assembly="EA.UUIRT.dll"
driver="EmbeddedAutomation.mServer.Adapters.UUIRTManager">
  <aparam name="DISPLAY-AS" value="USB-UIRT"/>
  <aparam name="Description" value="USB UIRT InfraRed Controller"/>
  <aparam name="Supports" value="UUIRT"/>
  <aparam name="AProtocol" value="UUIRT"/>
  <aparam name="FirstInternalDeviceId" value="-110"/>
  <aparam name="DebugLevel" value="5"/>
  <aparam name="BlinkOnReceive" value="true"/>
  <aparam name="BlinkOnTransmit" value="true"/>
</adapter>
```



To enable any changes in adapter XML settings, you must restart the mControl Automation Service, which during initialization reads the XML files.

Entering and Testing IR Commands

Navigate to the IR Control section to add or learn an IR command. To do this, from the Settings page, select IR Control. From the IR Control page, select the “Commands” tab. Select the “Add IR Command” button to add a new IR command.

Adding IR Commands (using CCF Format)

You can directly enter IR commands (in CCF format) into the IR Command field. For more information on CCF formats, please refer to: http://www.geocities.com/jpollack_2000/ccf.htm.

If you have access to CCF (Component Control File) codes for the command, it is possible to cut and paste them directly into the text box area.

- To get to CCF codes for your component, we recommend <http://www.remotecentral.com/>
- To convert binary CCF files to text format, we recommend utilities like the CCF Tools utility (also found on <http://www.remotecentral.com/>).



mControl only supports IR commands less than 1300 characters.

Learning IR Commands

If you have a GC-IRL (Global Cache IR Learner adapter connected to the GC-100 Network Adapter) or a USB UIRT, you can learn the IR command.


To do this, press the “Learn” button and within a 10 second time frame enter the command by pressing the remote control button while pointing at the GC-IRL or the USB UIRT. The command will appear in the text box in CCF format.



mControl only supports IR commands less than 1300 characters. To properly learn commands, it is recommended that you press and release the remote button you are learning – do not hold it down. Holding the button may send fill the IR buffer with unnecessary repetitive information.

Testing IR Commands

To test an added or learned IR command, use the “Test Output” selector to select the port where you would like to “blast” the IR command. Once selected, press the “Test” button to send the IR command through the selected port.



Sending IR commands within mControl Macros Actions

Within any macro, add an action of type “IR”, selecting a previously entered IR command.




Using IR commands as mControl Macros Triggers

mControl contains logic to recognize incoming IR signals and compare them to previously entered IR commands. If there is a match, it can be used to trigger a macro.

Within any macro, add a trigger of type “IR”, selecting a previously entered IR command. Any time that mControl recognizes this command, the macro will execute.

To effectively use IR macro triggers, a Global Cache RG-1 device is recommended.



IR Commands and Windows XP Media Center Edition 2005

A reference of Windows XP Media Center Edition 2005 CCF commands can be found here:

<http://www.remotecentral.com/cgi-bin/files/rcfiles.cgi?kw=media+center&fc=--&area=pronto&db=&br=&dv=&dt=&so=>

Please note, Windows XP Media Center Edition 2005 utilizes a two-code IR command toggle system to eliminate “bounce” or double keying. The debounce setting of Media Center can be disabled, thereby allowing a single command to represent the IR command. For a good reference on this topic, see: <http://blogs.msdn.com/mswanson/archive/2004/12/01/272766.aspx>.

Adding Voice Control

Basic Voice Control Operation

With One Voice Technologies' Media Center Communicator, mControl devices and macros can be operated via voice control.


1. Install One Voice Technologies' Media Center Communicator v2.x. Follow the instructions provided to properly set up and train Media Center Communicator.




Once installed, Media Center Communicator will allow you to control Windows Media Center functionality.



Outside of Media Center, the Media Center Communicator's status will also be visible in the system tray.




2. To initiate a bridge between Media Center Communicator and mControl, run the One Voice to mControl Bridge utility provided in the mControl Tools folder.



Once started, the One Voice to mControl Bridge utility will automatically connect to both the Media Center Communicator voice system and the mControl Automation Service.

In addition, the One Voice to mControl Bridge utility will automatically read the contents of the mControl database and generate a Media Center Communicator grammar file based on the devices and macros within the database.



Use the "Speak recognized commands" check box to hear a verbal response to commands.

3. To use voice control, simply issue voice commands in either of the following ways:

For lights and simple devices:

- “mControl, please turn <device> <command>” or “mControl, turn <device> <command>”
- “mControl, please turn <command><device>” or “mControl, turn <command><device>”

For mControl macros:

- “mControl, run <macro name>”

Extending Voice Control

Source code for the One Voice to mControl Bridge utility is provided as part the mControl Software Development Kit (SDK).

It is possible to extend the grammar file, allowing for greater flexibility in voice commands. The auto-generated grammar file is located in the C:\Program Files\Embedded Automation\mControl\tools directory and is called “mControl Grammar.jsg”. Do not adjust this manually.

Configuring mControl Clients

Using mControl from a remote PC using Internet Explorer

1. Start Internet Explorer and enter the following in the address area: `http://<mControl PC>:29990/default.aspx`, where "<mControl PC>" is the name or IP address of the PC on which mControl was installed on.

Adding mControl to a remote Windows XP Media Center Edition PC



Please note, this is an unsupported feature of mControl and once implemented, requires manual editing of your Windows registry – the mControl uninstaller does not remove these settings. We recommend making a back-up of your Windows registry before any substantive changes.

1. Copy the mControl.mcl file located in the "C:\Program Files\Embedded Automation\mControl" directory to the new client machine's "C:\Documents and Settings\<user of your choice>\Start Menu\Programs\Accessories\Media Center\Media Center Programs" directory.
2. Edit the file using Notepad to modify the URL, replacing 'localhost' with the name of the new client machine. For example, if your mControl Automation Service machine is called 'MyServer, you would change the URL setting to "<http://MyServer:29990/Default.aspx>".
3. Once the file has been modified, you will be able to access it from the "More Programs" area of the client machine.



If you refer to machine's name instead of the IP address, please ensure that the name is entered in the Windows Hosts file with the associated IP address, so Windows can resolve the machine's name. For more information on Hosts files: http://en.wikipedia.org/wiki/Hosts_file

Adding mControl to the Start Menu of a Windows XP Media Center Edition PC



Please note, this is an unsupported feature of mControl and once implemented, requires manual editing of your Windows registry – the mControl uninstaller does not remove these settings. We recommend making a back-up of your Windows registry before any substantive changes.

To use this function on a remote PC, first perform the step above to “Add mControl to a Remote Windows XP Media Center Edition PC”.

Only a maximum of two 3rd party items can be added to the “Start Menu” – so if two 3rd party items are already installed on the “Start Menu”, the following steps will have no effect.

1. Using Notepad or equivalent text editor, copy the following into a file called mControl.reg:

Windows Registry Editor Version 5.00

```
[HKEY_LOCAL_MACHINE\Software\Microsoft\Windows\CurrentVersion\Media
Center\Extensibility\Categories\Start Menu\{5688C348-8F19-4676-97F4-
5178A68C37EC}]
"AppID"="{aebf238a-a1c5-4354-ba23-e693cb9f219f}"
"TimeStamp"=dword:0add6130
"Title"="mControl"
"URL"="http://localhost:29990/Default.aspx"
```



Please ensure that the “[HKEY_LOCAL_ ... C37EC}]” line is not split into multiple lines in the mControl.reg file otherwise the key entry will be erroneous.

2. After saving the file, double-click on the file or, within Explorer, perform a right-click and select the “Merge” option. You will be asked if you want to add the information to the Windows registry. Once you agree, the registry settings will be added and mControl will be available on the “Start Menu” when Media Center is re-started.

Adding mControl to the More Programs Menu of a Windows XP Media Center Edition PC



Please note, this is an unsupported feature of mControl and once implemented, requires manual editing of your Windows registry – the mControl uninstaller does not remove these settings. We recommend making a back-up of your Windows registry before any substantive changes.

To use this function on a remote PC, first perform the step above to “Add mControl to a Remote Windows XP Media Center Edition PC”.

1. Using Notepad or equivalent text editor, copy the following into a file called mControl.reg:

```
Windows Registry Editor Version 5.00
```

```
[HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\Media
Center\Extensibility\Applications\{aebf238a-a1c5-4354-ba23-e693cb9f219f}]
"CompanyLogo"="C:\\Program Files\\Embedded
Automation\\mControl\\EmbeddedLogo.png"
"Description"="mControl for Windows MCE 2005"
"Title"="mControl"
"CompanyName"="Embedded Automation, Inc."

[HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\CurrentVersion\Media
Center\Extensibility\Categories\More Programs\{3de6904a-d9c7-4ef9-b77d-
c1216b39161f}]
"Title"="mControl"
"ThumbnailUrl"="C:\\Program Files\\Embedded
Automation\\mControl\\mHome_Thumbnail.png"
"Subtitle"="mControl for Windows MCE 2005"
"TimeStamp"=dword:09eea8e3
"AppId"="{aebf238a-a1c5-4354-ba23-e693cb9f219c}"
"ImageUrl"="C:\\Program Files\\Embedded Automation\\mControl\\EmbeddedLogo.png"
"Url"="http://localhost:29990/Default.aspx"
```

2. After saving the file, double-click on the file or, within Explorer, perform a right-click and select the “Merge” option. You will be asked if you want to add the information to the Windows registry. Once you agree, the registry settings will be added and mControl will be available on the “Start Menu” when Media Center is re-started.
3. Copy the files “EmbeddedLogo.png” and “mHome_Thumbnail.png” from the machine that mControl is installed in to the remote Windows Media Center PC. Change the entries “CompanyLogo”, “ThumbnailUrl”, and “ImageUrl” above to the directory where you have placed the copied images to.

Using mControl from a Windows Mobile Device

To view mControl's View Zone screen from a Windows Mobile device, use Internet Explorer on the device and access <http://<IP Address>:29990/mobile.aspx> (where <IP Address> is the address of the computer which is running the mControl Automation Service).



Adding mControl to SnapStream's Beyond Media

Add a mControl Entry Point to the Beyond Media Menu

- Navigate to directory where the file "Menus.xml" is located. The default location is *C:\Documents and Settings\All Users\Application Data\SnapStream\Beyond Media*
- Open the file "Menus.xml" with a text editor, like Notepad.exe.
- Find the following entry:

```
<MenuItem Id="Spotlight" Label="Spotlight" Image="SSBM_MainMenu_Spotlight">
  <MenuItem.Action>
    <ShowScreen Screen="Spotlight" ScreenArgs="http://www.snapstream.com/spotlight/" />
  </MenuItem.Action>
</MenuItem>
```

- Add the following entry directly below the entry above:

```
<MenuItem Id="mControl" Label="mControl" Image="">
  <MenuItem.Action>
    <ShowScreen Screen="mControl" ScreenArgs="http://[localhost]:29990/" />
  </MenuItem.Action>
</MenuItem>
```

- Replace [localhost] with the IP address of the PC running mControl.
- Save the changes to the "Menu.xml" file and restart Beyond Media
- Once Beyond Media is restarted, mControl should be under the main menu:



Add a mControl icon to the mControl Menu Entry

- Navigate to the Beyond Media skins directory. The default location is *C:\Documents and Settings\All Users\Application Data\SnapStream\Beyond Media\skins*.
- Using a text editor (e.g., Notepad.exe), open the desired skins XML file. Typical skins include: *BlueWave.xml*, *BTV.xml* or *Classic.xml*.
- Add an entry in the file for the mControl icon. The following example provides a path to the mControl.png file located under the “BTV” sub directory. **Make sure that the ID attribute is unique.**

e.g. `<Image Id="SSBM_mControl" Path="BTV\mControl.png" />`

- Place the image file in the corresponding directory, that is: *C:\Documents and Settings\All Users\Application Data\SnapStream\Beyond Media\skins\BTV*
- Open the file “Menus.xml” (as per the above instructions) and edit the mControl entry to use the Image ID name. Make sure that the Image attribute is equal to the Image ID of the image entry in the skins XML file.

```
<MenuItem Id="mControl" Label="mControl" Image="SSBM_mControl">
  <MenuItem.Action>
    <ShowScreen Screen="Spotlight" ScreenArgs="http://[localhost]:29990/" />
  </MenuItem.Action>
</MenuItem>
```

Configuring the mControl User Interface

mControl allows configuration of User Interface settings within the mControlDataSet.XML file, located within the \Program Files\Embedded Automation\mControl directory.



Before making any changes to the mControlDataSet.XML file, please make a back up. Please ensure all changes comply with XML - improper XML may affect the operation of mControl.



To enable any custom settings, you must restart the mControl Automation Service, which during initialization reads the XML files. Please make a back-up of any XML file before making changes.

Adding Custom Device Images

To add an image for a device, add a <device-image> element to the mControlDataSet.XML file.

- Images of type PNG, GIF, and JPEG are preferred. Image size should be 120 by 120 pixels for best display – other sizes will be scaled up/down to fit and may appear distorted.
- A blank image, called “Blank.gif” is provided in the “C:\Program Files\Embedded Automation\mControl\images\<platform folder>\<theme folder>\device” directory. You may use this image as a template for creating a custom device image.

In this sample, a “Chime” device, which uses the “Chime.gif” image has been added (shown in red).

```
<images>
  <device-image>
    <image-name>Chime</image-name>
    <image-file>Chime.gif</image-file>
  </device-image>
  <device-image>
    <image-name>Lamp</image-name>
    <image-file>Lights.gif</image-file>
  </device-image>
</images>
```

Adding Custom Options

Using the mControlDataSet.XML file, it is possible to adjust the following elements defined within the <configuration> section:

Element	Description	Default Values
<time-offset>	Defines the time offsets (in minutes) options for macro operations. Negative values indicate offsets before and positive values indicate offsets after the base time.	-60, -45, -30, -20, -15, -10, -5, +0, +5, +10, +15, +20, +30, +45, +60
<dimvalues>	Defines the options for dim granularity for a multi-level switch.	10, 20, 25, 50, 75
<onvalues>	Defines the options for on levels for a multi-level switch – used with device action within macros.	20, 40, 60, 80, 100
<delay-hours>	Defines the hours option value within a macro delay action.	0, 1, 2, 3, 4, 5, 6, 8, 10, 12, 24
<delay-minutes>	Defines the minutes option value within a macro delay action.	00, 01, 02, 03, 04, 05, 10, 15, 20, 30, 45
<delay-seconds>	Defines the seconds option value within a macro delay action.	00, 01, 02, 03, 04, 05, 10, 15, 20, 25, 30, 40, 50
<cam-vid-duration>	Defines the duration (in seconds) for a camera to keep recording within a macro device action.	1, 2, 3, 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60
<cam-vid-framerate>	Defines what frame rate the camera should record video in.	1, 2, 3, 4, 5, 10, 30
<cam-vid-framerate-disp>	This is tied to <cam-vid-framerate> this displays the options in a clear and more meaningful way.	1 fps, 2 fps, 3 fps, 4 fps, 5 fps, 10 fps, Best Possible
<cam-snap-interval>	Defines the time interval between consecutive camera snapshots in a macro action.	1, 2, 3, 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, 60
<cam-snap-pics>	Defines the number of snapshots to take in a camera macro action.	1, 2, 3, 5, 10, 15, 20, 25, 30

In the following sample, a 33% dim granularity has been added (as shown in red).

```
<configuration>
  <time-offset>-60|-45|-30|-20|-15|-10|-
    5|+0|+5|+10|+15|+20|+30|+45|+60</time-offset>
  <dimvalues>10|20|25|33/50|75</dimvalues>
  <delay-hours>0|1|2|3|4|5|6|8|10|12|24</delay-hours>
  <delay-minutes>00|01|02|03|04|05|10|15|20|30|45</delay-minutes>
  <delay-seconds>00|01|02|03|04|05|10|15|20|25|30|40|50</delay-
seconds>
</configuration>
```

Adding Custom Style Sheets

Using the mControlDataSet.XML file, it is possible to create or modify style sheets or “skins” for mControl.

mControl style sheets consist of the following elements:

Element	Description
<style-sheet>	Parent element which encapsulates the style sheet. id – defines the name of the “Style” which shows in the “Configuration” section of mControl.
<filename>	Child element which defines the associated html style sheet name (.css file) for the skin.
<imageDir>	Child element which defines the directory name for where the images for the skin are located.
<platforms>	Child element which defines the platforms available for the skin.
<javaMCE> <javaIE> <javaUMPC>	Child element which defines the JavaScript variables required for positioning data-related items within the mControl user interface framework. index – defines the array index for the JavaScript variable value – defines the value for the JavaScript variable
<MCE> <IE> <UMPC>	Child element which defines the XML variables required for defining the mControl user interface framework. name – defines the name of the XML variable value – defines the value of the XML variable

User Interface Platforms

mControl supports the following platforms:

- IE – for Internet Explorer 6.0 and higher clients
- MCE – for Media Center clients
- UMPC – for UMPC browser clients

If a selected style is not available for a platform, mControl will default to the “Blue – Static” style for that platform.

mControl Images

mControl uses graphic images to form elements on the screen. These images can be animated or static.

For a complete list of images to create for a new skin, please refer to the images located within the C:\Program Files\Embedded Automation\mControl\images\ie\blue_static directory.

Style Sheets

mControl uses external DHTML cascading style sheets (CSS) to define image and text sizes and formats.

The following table lists the classes required for a mControl skin:

Class	Description
<i>Common Application Objects</i>	
.appName	mControl image
.appInfo	mControl page
.appView	mControl page function
.background	Background image
.bodyClass	Body definition
<i>Buttons</i>	
.AllZone	Zone buttons (no focus)
.AllZone_hilite	Zone buttons (focus)
.Button	General button (no focus)
.Button_hilite	General button (focus)
.ButtonMini	Small button (no focus)
.ButtonMini_hilite	Small button (focus)
.MedButton	Medium button (no focus)
.MedButton_hilite	Medium button (focus)
<i>Radio Buttons</i>	
.CurrentZone	Current zone (no focus)
.CurrentZone_hilite	Current zone (focus)
.Zone	Zone buttons (no focus)
.Zone_hilite	Zone buttons (focus)

Class	Description
<i>Page Up/Down Buttons</i>	
.arrowL	Arrow left
.arrowR	Arrow right
.devDown	Device down (no focus)
.devDown_hilite	Device down (focus)
.devUp	Device up (no focus)
.devUp_hilite	Device up (focus)
.pageUp	Page up
.pageDown	Page down
<i>User Console Device Buttons</i>	
.devOn	Device on (no focus)
.devOn_hilite	Device on (focus)
.devOff	Device off (no focus)
.devOff_hilite	Device off (focus)
.devDim	Device dim (no focus)
.devDim_hilite	Device dim (focus)
.devBright	Device bright (no focus)
.devBright_hilite	Device bright (focus)
.devUp	Device up (no focus)
.devUp_hilite	Device up (focus)
.macRun	Macro play (no focus)
.macRun_hilite	Macro play (focus)
<i>User Console Blank Controls</i>	
.devImg	Device image
.devNameLbl	Device name label
.devStatus	Device status image
.macNoFnc	Empty image for macros
.devNoFnc	Empty image for devices
.devNoFncMini	Empty image for devices (small)

Class	Description
<i>Check Boxes</i>	
.blankBox	Unchecked box (no focus)
.blankBox_hilite	Unchecked box (focus)
.checkBox	Checked box (no focus)
.checkBox_hilite	Checked box (focus)
<i>Check Boxes</i>	
.infoBox	Info box
.infoBoxLrg	Info box (large)
<i>Spinner Buttons</i>	
.SpinnerBox	Spinner box
.SpinnerBoxSm	Spinner box (small)
.spinnerMBtnZ	Minus spinner button for dynamic data lists (no focus)
.spinnerMBtnZ_hilite	Minus spinner button for dynamic data lists (focus)
.spinnerPBtnZ	Plus spinner button for dynamic data lists (no focus)
.spinnerPBtnZ_hilite	Plus spinner button for dynamic data lists (focus)
.spinnerMBtn	Minus spinner button for static data lists (no focus)
.spinnerMBtn_hilite	Minus spinner button for static data lists (focus)
.spinnerPBtn	Plus spinner button for static data lists (no focus)
.spinnerPBtn_hilite	Plus spinner button for static data lists (focus)
<i>Text Fonts and Styles</i>	
.textControl	General text (no focus)
.textControl_hilite	General text (focus)
.hvacStatusText	HVAC status text
.devStatusText	General device status text
.errorText	Error text
.textMenuHeader	Menu header text
.textWhite	General white text
.textWhiteSmall	General white text (small)
.textDisabled	General text (disabled)

Class	Description
<i>Thermostat</i>	
.consoleThermo	Thermostat console image
.consoleThermoStatus	Thermostat status image
.devTexty	Thermostat text
.thermoCool	Thermostat cool mode image
.thermoHeat	Thermostat heat mode image
.thermoAuto	Thermostat automatic mode image
.thermoOff	Thermostat off mode image
.thermoFanOn	Thermostat fan on image
.thermoFanOff	Thermostat fan off image
.thermoFanAuto	Thermostat fan automatic image
.setpointHeatOn	Thermostat heat set-point on
.setpointHeatOff	Thermostat heat set-point off
.setpointCoolOn	Thermostat cool set-point on
.setpointCoolOff	Thermostat cool set-point off
.StatusThermo	Thermostat status image
<i>Sprinkler</i>	
.sprinklerValveOn	Sprinkler valve status on
.sprinklerValveOff	Sprinkler valve status off
.sprinklerProgOn	Sprinkler program status on
.sprinklerProgOff	Sprinkler program status off
<i>Security System</i>	
.consoleSecurity	Security console image
.consoleSecurityStatus	Security status image
.securityReady	Security status – ready
.securityNotReady	Security status – not ready
.securityArmed	Security armed status – armed
.securityNotArmed	Security armed status – not armed

Class	Description
<i>Scrollers and Counters</i>	
.counterDefaultLHS	Counter for LHS buttons (e.g., zones) for View Zone page.
.counterGeneral	Counter for general buttons (e.g., devices)
.scrollDefaultLHS	Scrolling Pane for LHS buttons for View Zone page
.scrollGeneral	Scrolling Pane for majority of mControl pages
.scrollLarge	A scrolling pane with larger dimensions
.menuSpan	Horizontal scrolling pane for all menu bars
<i>Triple-Tap and Input Fields</i>	
.tripleTap	Media Center general triple-tap input box
.spanTripleTap	Placeholder for a general triple-tap input box
.spanTripleTapMini	Placeholder for a mini triple-tap input box
.tripleTap2	IE / UMPC general input box (no-focus)
.tripleTap2_hilite	IE / UMPC general input box (focus)
.tripleTapMini	IE / UMPC mini input box placeholder (no-focus)
.tripleTapMini_hilite	IE / UMPC mini input box placeholder (focus)
.textControlSpan	General input box placeholder (focus)
.textControlSpan_hilite	General input box placeholder (focus)
.textControlSpanMini	Placeholder for a mini triple-tap input box
.textControlSpanMini_hilite	Placeholder for a mini triple-tap input box

Class	Description
<i>Camera</i>	
.camLeftBtn	Camera left button (no focus)
.camLeftBtn_hilite	Camera left button (focus)
.camRightBtn	Camera right button (no focus)
.camRightBtn_hilite	Camera right button (focus)
.camUpBtn	Camera up button (no focus)
.camUpBtn_hilite	Camera up button (focus)
.camDownBtn	Camera down button (no focus)
.camDownBtn_hilite	Camera down button (focus)
.camHomeBtn	Camera home button (no focus)
.camHomeBtn_hilite	Camera home button (focus)
.camZoomInBtn	Camera zoom in button (no focus)
.camZoomInBtn_hilite	Camera zoom in button (focus)
.camZoomOutBtn	Camera zoom out button (no focus)
.camZoomOutBtn_hilite	Camera zoom out button (focus)
.camTypePic	Camera type indicator image
.camTypeVid	Camera type indicator video

JavaScript Variables

mControl uses JavaScript variables to define how mControl data elements are positioned within the skin. Devices and zones are examples of mControl data elements.

The following table lists the JavaScript variables required for an mControl skin:



Used in Page	Array Index	Description
Default (View Zone)	0	Device objects vertical offset (top-to-top)
Default (View Zone)	1	Device label height
Default (View Zone)	2	Device image left
Default (View Zone)	3	Device status left
Default (View Zone)	4	Device label/on left
Default (View Zone)	5	Device off left
Default (View Zone)	6	Device dim left
Default (View Zone)	7	Device bright left
Default (View Zone)	8	Security armed left
Default (View Zone)	9	Security armed top
Default (View Zone)	10	Security ready left
Default (View Zone)	11	Security ready top
Default (View Zone)	12	HVAC font size
Default (View Zone)	13	HVAC text left
Default (View Zone)	14	HVAC mode left
Default (View Zone)	15	HVAC mode top
Default (View Zone)	16	HVAC fan left
Default (View Zone)	17	HVAC status top
Default (View Zone)	18	Button vertical offset (top-to-top)
Default (View Zone)	19	Camera preview width
Default (View Zone)	20	Camera preview height
ManageZones	21	Span objects vertical offset (top-to-top)
ManageZones	22	Zone up left
ManageZones	23	Zone down left
EditZone	24	Span objects vertical offset (top-to-top)
Automation	25	Span objects vertical offset (top-to-top)
General	26	Mini-button width
EditIRCommand	27	Code span width
EditIRCommand	28	Code span height
Automation	29	Arrow up left
Automation	30	Arrow down left
IRList	31	Span objects vertical offset (top-to-top)
ActionList	32	Span objects vertical offset (top-to-top)
ActionList	33	Item name left
ActionList	34	Arrow up left
ActionList	35	Arrow down left
SecurityView	36	Span objects vertical offset (top-to-top)




Used in Page	Array Index	Description
SecurityView	37	Partition item left
<i>General</i>	38	Maximum # characters to display onscreen LHS Buttons
<i>General</i>	39	Maximum # characters to display onscreen
Default (View Zone)	40	EZRain program left
Default (View Zone)	41	EZRain valve top
Default (View Zone)	42	EZRain valve vertical offset (top-to-top)
Default (View Zone)	43	EZRain 2nd valve list left
CameraView	44	Camera object width
CameraView	45	Camera object height
CameraList	46	Span objects vertical offset (top-to-top)




XML Variables





mControl uses XML variables to define how mControl user interface elements are positioned within the skin. Buttons and images are examples of mControl data elements.




The following table lists the XML variables required for a mControl skin:




XML Variable	Description
GENERIC_LHS_YOFFSET	<p>The space between the top of each left hand side buttons relative to each other.</p> 
GENERIC_LHS_TOP	<p>The space between the top of the left hand side buttons and the top of the page.</p> 




XML Variable	Description
<p>GENERIC_LHS_LEFT</p>	<p>The space between the left side of the page to the left hand side buttons.</p> 
<p>GENERIC_MAIN_TOP</p>	<p>The space between the top of the page and the elements displayed.</p> 
<p>GENERIC_MAIN_YOFFSET</p>	<p>The space between the top of one element to the top of the next element.</p> 




XML Variable	Description
<p>GENERIC_MAIN_LEFT</p>	<p>The space between the left side of the page to the elements displayed.</p> 
<p>GENERIC_MAIN_XOFFSET</p>	<p>The space between MAIN_XLEFT and the element to be displayed. The elements that are displayed on the right side of the Settings View are relative to their order (left to right) and the MAIN_XOFFSET value.</p> 
<p>SPACER</p>	<p>Generic variable used to place space between items on the page.</p> 




XML Variable	Description
GENERIC_SCROLL_OFFSET	<p>The height of each row inside scrollable list objects.</p>  <p>The screenshot shows a screen titled 'MANAGE ZONES'. On the left, there are buttons: 'Back', 'Home', 'Save', and 'Add Zone'. On the right, there is a list of zones: 'Zone 01', 'Zone 02', 'Cameras', 'ELK', and 'zone n'. Each zone has a vertical double-headed arrow to its left and up/down arrow buttons to its right. The screen has a blue background and a status bar at the bottom right showing '1 5' and some icons.</p>
GENERIC_SP_WIDTH	<p>The width of each set point text element.</p>  <p>The screenshot shows a screen with settings for 'Mode' (Auto), 'Fan' (Auto), and 'Setpoints'. Under 'Setpoints', there are two rows: 'Cooling' with a value of 28 and 'Heating' with a value of 16. Each row has a horizontal double-headed arrow to its left and up/down arrow buttons to its right. The screen has a blue background.</p>
GENERIC_TEXT_WIDTH	<p>The space between the left side of the text labels and the left side of the elements.</p>  <p>The screenshot shows a screen titled 'Configure main options' with a subtitle '1 of 2'. It has two tabs: 'Main' and 'Advanced'. Under the 'Main' tab, there are fields for 'Name' (idev), 'Adapter' (2414X-INSTEON), 'Module' (2456Dx), 'Insteon Address' (11.11.11), and 'Image' (Lamp). Each field has a horizontal double-headed arrow to its left and up/down arrow buttons to its right. The screen has a blue background.</p>
MENU_SPACER	<p>The space between the right end of MAIN_XLEFT to the beginning of the menu item.</p>  <p>The screenshot shows a screen titled 'CONFIGURATION' with a subtitle '1 of 2'. It has two tabs: 'Main' and 'Location'. Under the 'Main' tab, there are buttons for 'Back', 'Home', and 'Save'. There are also settings for 'Style' (Blue - Static) and 'Language' (English). Each setting has a horizontal double-headed arrow to its left and up/down arrow buttons to its right. The screen has a blue background.</p>




XML Variable	Description
MENU_ITEMS	<p>The number of menu items to display at once on the menu. The MENU_ITEM_WIDTH must be able to accommodate the number of items on menu; otherwise the some times may be hidden despite the value of MENU_ITEMS.</p> 
MENU_ITEM_WIDTH	<p>The width of each menu item.</p> 
ACTIONLIST_ROWS	<p>The number of items to display at once in the Macro Details View. It affects both the number of triggers and actions.</p> 





XML Variable	Description
AUTOMATION_ROWS	<p>The number of macros to display at once in the Automation View.</p> 
CAMLIST_ROWS	<p>The number of cameras to display at once in the Camera List View.</p> 
CAMVIEW_HEIGHT	<p>The height of the displayed camera image area. The displayed image can be smaller than the displayed image area (as shown in green) but cannot be bigger than the displayed image area.</p> 




XML Variable	Description
CAMVIEW_SPACER	<p>This moves the camera display area to the left edge of the screen. (Grey arrow represents the Generic_Main_Left)</p> 
CONFIG_MINITAP_SPACER	<p>Spacer for input controls on configuration page.</p> 
EDITZONE_ROWS	<p>The number of devices to display on the Edit Zone View.</p> 



XML Variable	Description
EZRAIN_MINITAP_SPACER	<p>The number of cameras to display at once in the Camera List View.</p> 
EZRAIN_SPACER	<p>The space from the left side of the number label to the left side of the valve icon.</p> 
EZRAIN_VALVE_YOFFSET	<p>The distance between each valve status indicator (top-to-top).</p> 

XML Variable	Description
EZRAIN_VALVE_TOP	<p>The space between from MAIN_YTOP to the top of the first valve icon.</p> 
EZRAIN_VALVE_LEFT	<p>The width of the first status panel and the text of EZRain.</p> 
IRLIST_ROWS	<p>The number of IR commands/adapters to display at once in the IR List View.</p> 

XML Variable	Description
MANAGEZONE_ROWS	<p>The number of zones to display at once in the Manage Zones View.</p> 
SECURITY_ROWS	<p>The number of Elk security zones to display at once in the Security View</p> 
SECURITY_STATUS_LEFT	<p>The space between MAIN_XLEFT (orange) to the status panel of ELK in the Elk View.</p> 

XML Variable	Description
SECURITY_STATUS_WIDTH	<p>The width of the first status panel in the status area of Security View.</p> 
SECURITY_STATUS_TOP	<p>The space between the top of the “Ready” icon to the “Armed” icon</p> 
HVAC_STATUS_WIDTH	<p>The width for each HVAC status indicator.</p> 
HVAC_STATUS_LEFT	<p>The space between MAIN_XLEFT (orange) to the status panel of HVAC in the HVAC View.</p> 

XML Variable	Description
VIEWZONE_MAIN_YOFFSET	<p>The distance between each device item in the zone view page.</p> 
VIEWZONE_MAIN_LEFT	<p>The space between the left side of the page to the beginning of the elements in the Zone View.</p> 
VIEWZONE_MAIN_ROWS	<p>The number of devices to display at once in the Zone View (home) page.</p> 

XML Variable	Description
VIEWZONE_LHS_ROWS	<p>The number of zones to display at once in the Zone View (home) page.</p> 
CAMRECORD_ROWS	<p>The number of media items to display at once in the Camera Media.</p> 

mControl Editor

mControl setup automatically installs the mControl Editor utility, which can be used to quickly and easily manage mControl data.

Use the mControl Editor utility to:

- Add, Remove and Modify Zones information
- Add, Remove and Modify Device information




Please ensure that you back-up your mControl.mdb file before making any changes using the mControl Editor. The mControl.mdb file contains information on your zones, devices, macros, actions and general configuration information. This file is generally located in the “Program Files\Embedded Automation\mControl\data” directory.



Additional features will be added to the mControl Editor to allow for other editing and configuration features. Please check the Embedded Automation website for new versions of the mControl Editor.

Starting the mControl Editor

The mControl Editor is automatically installed and is accessible from the “mControl” folder in the mControl program area:




Once started, the mControl Editor automatically connects to the mControl Automation Service and retrieves the current configuration.



To use the mControl Editor, the mControl Automation Service must be running.

Though mControl can be used while the mControl Editor is running, to ensure data integrity, it is recommended they not be used concurrently to change mControl data. Simultaneous changes may result in erroneous data.



mControl Editor Menu

The mControl Editor Menu provides the following menu options:

File options

Connect – connects to the mControl Automation Service and retrieves mControl data.

Exit – disconnects from the mControl Automation Service and exits the mControl Editor.

Editing Zones

To add, delete or modify zones, first select the “Manage Zone” tab within in the mControl Editor Functions. Once selected, a tree view of all zones and their associated devices will be shown.

To modify the zone name, select the zone to be modified in the mControl Data (Tree View). Once selected, the zone's information will be shown in the mControl Data Area (Detail View). Modify the zone name within the “Zone Name” field and press the “Save Changes” button.

To delete a zone, select “Zones” on the tree's root, then select the zone to delete in the mControl Data (Grid View) and press the Delete key.

To add a zone, select the root of the tree, which is labeled “Zones”. Once selected, the mControl Data Area (Detail View) will display an empty “Zone Name” field. Enter a new zone within this field and press the “Add Zone” button.

Editing Devices

To add, delete or modify devices, first select the “Manage Zone” tab within in the mControl Editor Functions. Once selected, a tree view of all zones and their associated devices will be shown.

To modify a device, select the device to be modified in the mControl Data (Grid View). Once selected, the device’s information will be shown in the mControl Data Area (Detail View). Modify the device’s information and press the “Save Changes” button.

To delete a device, select the device to delete in the mControl Data (Grid View) and press the Delete key.

To add a device, select the zone in which you would like to create the device within. Once selected, the mControl Data Area (Detail View) will display fields, some filled with default values, associated with new device. Enter the information for the new device and pres the “Add Device” button.

Version History

v1.70 – released January 2007

Issue #	Description
220, 224, 244, 248, 325, 338, 511, 532, 537, 575, 755, 761, 773, 791, 839, 856, 857, 858, 859, 860, 868, 871, 874, 881, 883, 885, 892, 940, 942	Enhanced security camera support, including: <ul style="list-style-type: none"> Support for Panasonic cameras (BB-HCM331) Confirmed support for D-Link DCS-3220 and DCS-6620 series of cameras Enhanced Camera View page provides capability to take a snapshot, record a video and, if camera allows, perform pan-tilt-zoom functionality New macro trigger: On Camera Motion (supported on Axis cameras) New macro action: Record video (user-definable frame rate and duration) New macro action: Take snapshot (user-definable count) New Camera Media page allows viewing of snapshots and videos, sorted by date/time, media type or camera View camera snapshots and videos within Media Center
743, 869, 870, 876, 893, 894, 897, 898, 899	Enhanced security system support, including: <ul style="list-style-type: none"> Support for DSC PowerSeries Security Systems (via PC5401 module) Support for Honeywell Ademco Security Systems Touch screen friendly numeric entry buttons for arming/disarming
253, 771, 780, 785, 865, 891, 910, 923	Enhanced device support, including: <ul style="list-style-type: none"> Support for HAI RC Thermostats Support for USB UIRT IR Receiver/Blaster
846, 889	Z-Wave protocol enhancements, including: <ul style="list-style-type: none"> Z-Wave Adapter Utility has been improved to display Z-Wave device information Improved robustness to manage lost connections
119, 124, 906	X10 protocol enhancements, including: <ul style="list-style-type: none"> Universal Module (UM506) support Enhancements to CM17 (Firecracker) communications
191, 383, 392, 778, 851, 907	User Interface enhancements, including: <ul style="list-style-type: none"> Support for SnapStream's BeyondMedia media center New Windows Mobile interface provides view and control of mControl devices Button like behavior on devices
900	Enhanced voice recognition capabilities (using One Voice Technologies' Media Center Communicator) <ul style="list-style-type: none"> mControl macros can now be triggered by voice command
125, 534, 818, 828, 830, 831, 832, 911, 912, 913, 931, 932, 939	Enhanced macro functionality <ul style="list-style-type: none"> Ability to specify images for each macro Ability to order macros within a zone Set durations for macro actions to allow for deterministic macro timing
213, 223, 758, 764, 807, 808, 815, 827, 838, 842, 847, 848, 850, 864, 872, 873, 890, 902, 905, 921, 922, 925	Many general enhancements to mControl including: <ul style="list-style-type: none"> User interface Installation process User Manual

v1.60 – released September 2006

Issue #	Description
799, 801	One Voice Technology (voice recognition) integration. Source code and grammar file is provided to allow functionality extensions by users.
	<p>New Software Development Kit (SDK) to allow developers to create applications which can interface to mControl. The SDK includes:</p> <ul style="list-style-type: none"> ▪ mControl SDK manual with detailed information on the mControl application programming interface (API) ▪ Sample source code projects which interface programmatically with mControl, including macro operation and event handling
814, 820, 821	<p>New user interface choices and related documentation:</p> <ul style="list-style-type: none"> ▪ New “grey skin” which provides a more condensed view including more zones and devices in the View Zone page ▪ Documentation to allow customization of user interfaces
786, 787, 788, 789, 790, 792, 793	<p>Enhanced macro functionality including:</p> <ul style="list-style-type: none"> ▪ Capability to trigger on Elk security alarms or arming/disarming ▪ Capability to set HVAC values within a macro action
800	Support of Global Cache RG-1 (long-range IR receiver) which can be used for macro triggering.
768, 770, 776, 823	<p>Enhanced security camera support including:</p> <ul style="list-style-type: none"> ▪ Static JPG image viewing with auto-refresh (instead of video stream)
795, 796	<p>Enhanced X10 support including:</p> <ul style="list-style-type: none"> ▪ Better handling of X10 input for status updates and macro triggers ▪ Improvements to X10 message handling for HVAC operations
772, 775, 782, 817, 831	<p>Many general enhancements to mControl including:</p> <ul style="list-style-type: none"> ▪ User interface ▪ Installation process ▪ User Manual

v1.50 – released June 2006

Issue #	Description
141, 171, 252, 273, 390, 546, 551, 558, 563, 564, 565, 566, 567, 569, 573, 574, 579, 590, 591, 592, 595, 596, 597, 598, 599, 600, 601, 602, 608, 609, 611, 614, 619, 620, 631, 633, 634, 635, 637, 642, 708, 710, 711, 716, 721, 724, 726, 728, 729, 736, 737	<p>Enhanced macro functionality including:</p> <ul style="list-style-type: none"> ▪ Macros now allow for multiple triggers ▪ Time-based triggers/actions allow for randomization to prevent detection ▪ Additional triggers have been added, including: <ul style="list-style-type: none"> • IR Event – trigger on recognized IR message • MCE Event – trigger on Media Center event (e.g., DVD Play) • One Time – trigger once at a specific time • Device (Group) – trigger on incoming INSTEON group message ▪ Additional actions have been added, including: <ul style="list-style-type: none"> • Macro Action – call another macro • Send Mail Action – send an email • External Action – launch an external application
204, 562, 605, 606, 660, 664, 665, 666, 669, 672, 674, 675, 676, 694, 695, 701	<p>Support for Elk Security's M1 security system, including the ability to:</p> <ul style="list-style-type: none"> ▪ View the status of each zone ▪ Arm and disarm the system
654, 656, 680, 681, 683, 688, 703, 706	<p>Support for EZRain Irrigation System, including the ability to:</p> <ul style="list-style-type: none"> ▪ View the status of the EZRain Irrigation System ▪ Program times for each valve ▪ Ability to start the EZRain device with mControl macros
176, 246, 264, 492, 497, 498, 639, 653, 741	<p>Enhanced security camera support including:</p> <ul style="list-style-type: none"> ▪ Support for Axis cameras ▪ Support for host.domain.com addressing ▪ Infrastructure to add cameras not currently supported by mControl
581, 589, 687, 689	<p>Enhanced user-interface infrastructure, which allows for:</p> <ul style="list-style-type: none"> ▪ Support for alternate screen sizes, in particular, Ultra-mobile PC (UMPC) screen sizes – including Samsung Q1
491, 533, 584, 641, 655, 691, 698	<p>Enhanced support of Z-Wave protocol, including:</p> <ul style="list-style-type: none"> ▪ Greatly enhanced Z-Wave Adapter Utility which supports replacement/deletion of failed nodes, Secondary/Primary adapter role management and device polling management ▪ Support for the Intermatic USB adapter
064, 237, 332, 349, 487, 509, 536, 545, 735, 745, 747, 749	<p>Enhanced support of INSTEON protocol, including:</p> <ul style="list-style-type: none"> ▪ Support for latest version of Powerline Controllers (PLCs)
45, 157, 180, 207, 301, 535	<p>Enhanced support of X10 protocol, including:</p> <ul style="list-style-type: none"> ▪ Support for the W800RF32A X10 RF receiver. The W800RF32A receiver allows direct receipt of wireless X10 messages. ▪ Support for Leviton modules which utilize "Extended X10" messaging. This support provides for 2-way communications, including status updates and macro triggering and enhanced dim/brighten control.
085, 099, 123, 159, 202, 271, 279, 283, 284, 285, 286, 290, 294, 298, 316, 369, 371, 384, 396, 457, 474, 494, 501, 514, 521, 541, 550, 552, 553, 554, 559, 576, 577, 593, 594, 613, 616, 621, 627, 629, 643, 678, 679, 680, 690, 692, 699, 700, 707, 709, 718, 722, 723, 730	<p>Many general enhancements to mControl including:</p> <ul style="list-style-type: none"> ▪ mControl directory infrastructure ▪ Installation process ▪ User Manual

v1.40 – released March 2006

Issue #	Description
209, 215, 226, 387, 393, 401, 447, 458, 460, 519	INSTEON enhancements, including: <ul style="list-style-type: none"> Confirmed support of ICON Switches (INSTEON 2876DB & 2876SB) Enhanced support to allow for macro-triggering and screen updates for SwitchLinc and KeypadLinc Added support for Preset Dim and Ramp Rates Improved robustness for receiving X10 commands
28, 395, 405, 411, 412, 414, 424, 425, 426, 427, 428, 429, 430, 431, 433, 434, 436, 449, 450, 451, 452, 453, 455, 456, 461, 463, 473, 476, 479, 490, 493, 512, 517	Added support for the Z-Wave protocol and associated devices, including: <ul style="list-style-type: none"> Support for PC adapters operating in either primary and secondary controller mode Added support for binary (appliance) devices, multi-level/dimmable (lamp) devices and thermostats New Z-Wave Controller utility. This utility allows for convenient configuration of Z-Wave controllers. Real-time status updates as defined by polling rate Added support for Preset Dim
156, 324, 398, 404, 406, 407, 408, 409, 410, 464, 465, 468, 470, 472, 477, 481, 507, 516	Added support for RCS Thermostats, including: <ul style="list-style-type: none"> TXB16 X10 Thermostat TZ16 Z-Wave Thermostat
445, 467, 488	Added support for additional security cameras, specifically: <ul style="list-style-type: none"> D-Link DCS-900, DCS-900W, DCS-3220 and DCS-3220G cameras
402, 496	Enhanced support for CM11A/CM12 adapters to allow for the ability to receive incoming X10 messages. This functionality allows for real-time status updates, device macro triggers and thermostat support.
415, 416, 417, 419, 420, 421, 422, 438, 441, 446, 478, 508	New “mControl Editor” utility. For this version, the mControl Editor supports the following functionality: <ul style="list-style-type: none"> Viewing mControl Zone and Device data in a grid/tabular format Allows for easy addition, deletion and editing of Zones and Devices
513	New “mServer Service Manager” utility. This utility allows for convenient control of the mControl Automation Service.
489, 526	Enhanced IR functionality, including: <ul style="list-style-type: none"> Increased IR command buffer to 1300 characters Added button to allow immediate testing of learned commands
320, 357, 370, 378, 394, 397, 399, 400, 437, 442, 443, 444, 448, 471, 480, 483, 485, 486, 500, 504, 505, 515, 520	Many general enhancements including: <ul style="list-style-type: none"> Improved robustness Macro operation Documentation UI improvements

v1.31 – released December 2005

Issue #	Description
317,341,350, 354, 356	Improved robustness for installation, logging and copy protection, including: <ul style="list-style-type: none"> ▪ Installation in non-default directory or drive ▪ Size and number of log files can be set ▪ Proper version is shown in “More Programs” area of MCE ▪ Automatic upgrading of v1.1x database adds necessary fields
158,336,348	Improved robustness for editing of mControl devices, zones and related data.
323,355	Improved robustness for Macro handling, including: <ul style="list-style-type: none"> ▪ Will not allow selection of undefined addresses as triggers
205,206,225, 299,302,313, 329,340,343, 345,347,351, 360,361,366, 367,368,372, 373,377,380	Improved robustness related to INSTEON and X10 support, including: <ul style="list-style-type: none"> ▪ Elimination of spurious exception errors ▪ Improved automatic handling of plugging and unplugging of CM15A and 2414U ▪ Behavior for INSTEON devices changed to reflect expected behavior instead of X10 behavior ▪ Multiple X10 ON commands handling ▪ Devices, if linked in mControl/2414U, will update status if ControlLinc, SwitchLinc or KeypadLinc also have them linked and change status ▪ Incoming and outgoing X10 messages on 2414U INSTEON adapter ▪ Improved robustness for automatic linking and unlinking of devices in PowerLinc's database

v1.30 – released November 2005

Issue #	Description
238	Confirmed support of Windows XP Media Center Edition 2005 Rollup 2
33 ,221,228, 235,236,268, 269,274,275, 280,297,307, 311,322	Enhanced Macro support, including: <ul style="list-style-type: none"> ▪ Support for sunrise and sunset macro triggers. Configuration allows for entry of longitude and latitude, thereby allowing mControl to calculate the sunrise and sunset for the day. Offsets can be added to control desired trigger points relative to sunrise and sunset. ▪ Greater than 6 hours for delays ▪ Enhanced error checking for incorrect macro triggers and actions
100,169,259, 277,278,296, 312,321	Added support for IR functionality, including: <ul style="list-style-type: none"> ▪ Support for the Global Caché Network IR Adapter, including “learning” functionality (using GC-IRL module) ▪ Support for raw Component Control Files (CCF), thereby allowing manual entry, using cut and paste, of known IR commands
90,193,203, 242,243,261, 265,266,267, 270,276,282, 287,300, 306	Enhanced configurability, including: <ul style="list-style-type: none"> ▪ Selectable styles (or “skins”). Default style is now non-animated Blue, to ensure optimum performance for MCE environments. ▪ Expanded XML configuration files and related documentation. Please refer to the “Configuring mControl” section of the mControl User Manual
94 ,133,139, 164,199,222, 236,240,262, 275, 280,295	Performance improvements, including: <ul style="list-style-type: none"> ▪ mControl no longer throws an exception if stopped or restarted ▪ Memory management is no longer affected by presence or absence of internet connection ▪ Performance of the mControl client, when used in conjunction with Shared View Port (SVP) is greatly improved ▪ Improved entry field validation throughout

v1.30 – released November 2005 (continued)

Issue #	Description
218,225,241, 243,249,308, 309, 310,315, 318, 319,328, 331	<p>Enhanced support of the INSTEON protocol, including:</p> <ul style="list-style-type: none"> ▪ Added automatic linking and unlinking of INSTEON devices. All devices added to mControl zones will automatically be added to the 2414U PowerLinc's memory, thereby allowing the PowerLinc to recognize the device during 2-way communications. If the device is deleted from mControl, it will be automatically removed from the PowerLinc's memory. This eliminates the need for the user to do manual linking and unlinking. ▪ Added X10 to INSTEON command translator. Entries in the mServer.exe.xml configuration file will allow incoming X10 signals to be translated into a specified INSTEON address. This is particularly useful for cases where hybrid systems exist and rely on a X10-based back-end controller and INSTEON-based lighting control. ▪ Confirmed support for 2486D (INSTEON KeypadLinc) ▪ Improved incoming X10 event handling ▪ INSTEON Adapter/Device and FAQ sections has been updated
130,177,200, 212,231,232, 233,239	<p>Improvements to the mControl installer, including:</p> <ul style="list-style-type: none"> ▪ mControl database and license are backed up (.cpy extension) ▪ Improved installation of 3rd party software (e.g., CM15A X10 drivers) ▪ Default install is for "Everyone" to ensure that mControl is visible to MCE Extenders ▪ DLLs are properly registered and loaded in .NET Global Assembly Cache
168,195,214, 216, 242	<p>Documentation improvements, including:</p> <ul style="list-style-type: none"> ▪ Provided a section which describes how to remote mControl to another PC using either Internet Explorer or as a part of the "More Programs" section of Media Center ▪ Provided a section which describes how to add mControl to the "Start Menu" of Media Center ▪ Provided a section related to Custom User and System Configuration Settings. ▪ Provided information on how to use mControl when no active Internet connection is established.

v1.20 – released September 2005

Issue #	Description
13, 67	User interface will now update, in real-time, any device status changes. These changes may have been initiated by the user, by another user on a remote client or via macro actions.
31	Added support for security cameras. Specifically, the following cameras are now supported: <ul style="list-style-type: none"> ▪ D-Link DCS-2100+ ▪ D-Link DCS-5300W
90,131, 179	An XML file has been created to hold device configuration information. Users may now: <ul style="list-style-type: none"> ▪ Create custom images for a device, using “blank.gif” ▪ Rename devices (e.g., for localization purposes) ▪ Add/remove devices from the device list
93,129, 162,187	Page Up/Down buttons are now fully implemented and are usable for touch screen applications.
132,134, 150,153, 158,159	Macro functionality has been enhanced: <ul style="list-style-type: none"> ▪ Bright/Dim are available as action commands ▪ Added “day” settings to allow running of a macro on specific days ▪ Timer macros are now stored properly in the mControl database ▪ Macros now reference Zones/Devices properly ▪ Finer granularity on delay action steps
137	External INSTEON device changes can be used to trigger events. NOTE: To avoid infinite recursion, please ensure any actions within the macro do not retrigger the same macro.
170	Configurable Dim/Bright granularity is supported for each dimmable device.
136,138, 143,145	INSTEON support enhancements, including: <ul style="list-style-type: none"> ▪ Successive INSTEON commands issued within a macro will now properly execute. Previously, it was possible that some commands would not be processed due to the capability of the 2414x adapter. ▪ Remote commands, for example, from a ControlLinc or a SwitchLinc are now recognized by the adapter.
184,197	General usability enhancements, including: <ul style="list-style-type: none"> ▪ Confirmed Windows XP Home Edition support ▪ Installer has been enhanced to allow mControl installation in user selected drive and directory ▪ User no longer has to uninstall old version and install new version.

v1.11 – released on August 3, 2005

Issue #	Description
	The mControl User Manual, specifically the “Using mControl” section, has been updated to reflect the changes made for mControl v1 (Home Edition) release
135,136	Several enhancements to the INSTEON protocol driver including: <ul style="list-style-type: none"> ▪ All outgoing commands check if PowerLinc (USB) adapter is connected or disconnected, and will update the mControl database accordingly ▪ A 2 second timeout (and retry) strategy is included to ensure robust communications. ▪ Devices within the mControl database will be updated upon receipt of a corresponding event. Previously, the status change was only recorded if it was initiated by an mControl INSTEON command

v1.10 – released on July 21, 2005

Issue #	Description
10	The mControl User Interface Client is now fully supported on browsers based on Internet Explorer 6.
16, 17	Validated support for additional X10 adapters, modules, transceivers, remotes and sensors. In addition to supporting these devices within mControl, the User Manual and web site have been updated to reflect this support.
26, 65	To allow easier entry of devices, upon selecting Add Device, mControl will preload the house and adapter, based on the previous device entered.
29, 71, 82, 83, 88, 99	Improvements to the mControl User Interface Client including: <ul style="list-style-type: none"> ▪ Additional device images have been provided. ▪ Improved cursoring and paging within zones with many devices ▪ Improved consistency in screen names and navigation ▪ Consistent location of navigation and add/delete/edit buttons ▪ Ability to enable/disable Macros with single check box ▪ Error screens with recovery suggestions
54, 57	Increased robustness to CM11A adapter interface. A command retry strategy has been added to ensure that all commands are sent.
61	Older versions of mControl database are now automatically converted to latest version.
77, 78, 106	Managed deletions of Devices and Zones: <ul style="list-style-type: none"> ▪ A warning is given upon Device Deletion to alert that related Macro Actions may be affected. If confirmed, all associated Macros Actions are deleted. ▪ A warning is given upon Zone Deletion to alert that underlying Devices and associated Macros and their Actions may be affected. If confirmed, all underlying Devices are now marked as deleted and all associated Macros and their Actions are deleted.
101	User-selectable logging as defined in “mServer.exe.config” configuration file. The default setting is ALL.
102	mControl now supports COM1 through COM4 ports for all serial-based adapters.
103	Support for INSTEON protocol, specifically the 2414 PowerLinc adapter. mControl allows sending commands to both INSTEON and X10 modules. In addition, mControl will process commands received on this adapter. Please refer to the “Supported Automation” section of this manual for more details.
104	mControl now supports receiving X10 messages using a CM15A adapter. Received power line and RF commands can be processed to update the database or launch Device Macros. Please refer to the “Supported Automation” section of this manual for more details.

v1.00 (Release Candidate 1) – released on June 13, 2005

Issue #	Description
15, 34, 48	mControl Automation Service now provides user interface screens to mControl User Interface Client. IIS is no longer required.
40	Updated software interface for X10 CM15A ActiveHome Interface (USB)
81, 82, 84, 91, 93	Improvements to mControl User Interface Client including: <ul style="list-style-type: none"><li data-bbox="467 506 1333 533">▪ User will be prompted for saving edits if Back or Home button are pressed<li data-bbox="467 539 1240 567">▪ Current location or function is displayed over mControl watermark<li data-bbox="467 573 1062 600">▪ Home button for easy return to Zone View screen<li data-bbox="467 606 1013 634">▪ Amalgamation of the Create and Edit buttons<li data-bbox="467 640 878 667">▪ Use of mControl logo throughout<li data-bbox="467 674 1135 701">▪ Mouse functionality matches remote control functionality

Known Issues

All of the below-mentioned issues will be resolved in future versions of mControl:

Issue #	Description
95	<p>If the mControl Automation Service is not running the mControl User Interface Client does not come up on MCE or IE. There is a "Page Not Found" error.</p> <p>NOTE: Restart mControl Automation Service</p>
79	<p>It is possible to create non-unique device name and zone name combinations. For example, it is possible to create two devices with the same name within a zone or devices with the same address.</p> <p>NOTE: Please ensure that addresses, device names and zones are unique.</p>
69	<p>First time entry in to mControl may take >30 seconds.</p> <p>NOTE: Subsequent entries will be almost immediate.</p>
525	<p>It is possible to change select set points outside the temperature range.</p> <p>NOTE: The TXB16 and TZ16 will not accept set points outside of the range of the control range.</p>
527	<p>Due to the way the 2414U INSTEON adapter handles incoming X10 commands, TXB16 status display may be incorrect.</p> <p>NOTE: Consider using CM11A interface</p>

Error Management

The following summarizes mControl error conditions and suggested actions:

Errors	Description
<ul style="list-style-type: none"> AUTOMATION SERVER IS NOT RUNNING PAGE NOT FOUND SERVER IS NOT STARTED YET 	Please ensure that the mControl Automation Service is running. Use Control Panel's Administrative Tools and select Services. Within the Services manager, cursor to the "mHome Automation Server". If this service is stopped, then right-click to 'Start' or press the play button on the tool bar.
<ul style="list-style-type: none"> NO ZONES IN DATABASE 	In order to create a macro, there must be a minimum of one zone in the system. Please go back and enter a zone before continuing with the automation controls.
<ul style="list-style-type: none"> SERIAL PORT TIMEOUT EXCEPTION 	Please ensure that the CM11A/CM12U adapter is connected to your PC.
<ul style="list-style-type: none"> MACRO NOT READY MACRO ALREADY LOADED 	Macro failed. Please retry or review log files.
<ul style="list-style-type: none"> MACRO ALREADY RUNNING 	Macro failed. An instance of this macro is already running.
<ul style="list-style-type: none"> PROTECTION FAILED LICENSE FILE NOT FOUND VALIDATION OF MODULE FAILED DEMO LICENSE HAS EXPIRED LICENSE FILE IS TAMPERED WITH PROTECTION WRONG TAG SYSTEM DATE IS TAMPERED WITH 	mControl license has expired, is missing or has been damaged. Please contact support@embeddedautomation for further assistance.
<ul style="list-style-type: none"> SYSTEM ERROR 	mControl has encountered an unknown error, please restart mControl and try again.

Frequently Asked Questions (FAQs)

Installation and Start-up

I receive an "Unable to Display Page" error when I try to start mControl from Windows Media Center. The message says "Media Center is unable to load the page <http://localhost:29990/Default.aspx>."

This is because the mControl Automation Service is not running. Please 'Start' the mControl Automation Service, by going to the Control Panel's Administrative Tools and selecting Services. Within the Services manager, cursor to the "mHome Automation Service". Right-click to 'Start' or press the play button on the tool bar.

Can I use Internet Explorer to run mControl?

Yes, mControl will run on Internet Explorer. To start mControl type <http://localhost:29990/> into the Internet Explorer address area.

How do I access mControl from another Windows XP Media Center Edition 2005 machine?

mControl consists of two parts: (a) mControl Automation Service and (b) mControl User Interface Client(s). By default, mControl installs both of these on the same machine. Since the mControl Automation Service supports multiple clients, you can easily add a MCE client(s). (This is particularly useful if you've installed mControl on a Windows XP Professional machine.)

Simply copy the mControl.mcl file located in the "C:\Program Files\Embedded Automation\mControl" directory to the new client machine's "C:\Documents and Settings\<user of your choice>\Start Menu\Programs\Accessories\Media Center\Media Center Programs" directory. Edit the file using Notepad to modify the URL, replacing 'localhost' with the name of the new client machine. For example, if your mControl Automation Service machine is called 'MyServer', you would change the URL setting to "<http://MyServer:29990/Default.aspx>". Once the file has been modified, you will be able to access it from the "More Programs" area of the client machine.

I get a "The trial version of mControl has expired" message. What happened?

The mControl software you are using has been provided for limited time use. This is governed by a form of copy protection. Either one of three things happened to cause the "The trial version of mControl has expired" message: (a) the 30 days you had to review mControl has passed, (b) the mControl license has become damaged, or (c) the system date has been changed.

Please note: if your license has expired, all navigation and viewing functionality will still be available; however, all device control and automation will be disabled.

You can purchase mControl from the Embedded Automation web store.

X10 Automation

I don't see the X10 module I would like to control in the module list on the "Edit Device" screen.

You can add, remove or rename devices by making changes to the "mServer.exe.xml" file. Please refer to the "Configuring Devices" section of the mControl v1 (Home Edition) User Manual.

I plugged in my CM15A X10 Adapter and Windows asked for driver files. I pressed 'Cancel' but now I see unknown devices (denoted by yellow question marks) in Device Manager. What should I do?

To fix this simply install mControl. mControl will ask to install the required drivers for the CM15A X10 Adapter.

Z-wave Automation

My Z-wave device does not enroll – what is going wrong?

Please ensure that you have previously un-enrolled the device. If it was associated with a different Z-Wave network, it will not enroll.

INSTEON Automation

Does mControl work with SwitchLincs?

mControl can turn on, turn off, dim and brighten SwitchLincs.

In addition, mControl can sense paddle presses made by users. Paddle presses can also be used as triggers for macros. For more information on how to use paddle presses see the INSTEON section of the mControl v1 (Home Edition) User Manual.

mControl does not appear to receive device triggers, what could be happening? The 2414U INSTEON adapter LED blinks On and Off about every 1 second, what could be happening?

The memory in the 2414U INSTEON Adapter's memory may be "corrupt". Please email support@embeddedautomation.com – we can provide a utility to revert the 2414U to factory conditions.

Elk Security

I don't get the proper status from my Elk security system – what could be going wrong?

Please confirm that you have properly set the communication port and baud rate settings in the mServer.exe.xml configuration file. To check your Elk security baud rate settings refer to Menu 07 (Global System Definitions).

Also, confirm that you have selected the proper area (partition) to view.

HVAC

Why does the mControl user interface not display the TXB16 HVAC device status even though I added the device with correct address?

The TXB16 X10 HVAC requires about several minutes for communication as several X10 commands are sent to and from the device. When the device is initially added, please do not send any other INSTEON or X10 commands to allow the HVAC device to communicate successfully with mControl.

Support

Log Files

Log files contain journalized information of mControl operation, informational messages and errors. Log files can be found in the following folder: C:\Program Files\Embedded Automation\mControl\logs.

Log files are named mControl<xxx>.log, where <xxx> represents a numeric value. The most recent log file is mControl1000.log. If this log is full, it is renamed to mControl1001.log and a new mControl1000.log is opened for use. Up to 10 log files can exist, named incrementally, via this cascading copying progress.

Log files are also available for the MCE Add-in. These log files can be found in the following folder: C:\Program Files\Embedded Automation\mControl\logs. Log files for the MCE Add-in are named MSASAddIn<xxx>.log, where <xxx> represents a numeric value. As with mControl log files, these files are enumerated similarly.

Contact Us

Send us an email to: support@embeddedautomation.com or go to the Support page at www.embeddedautomation.com.

Participate in the forum: www.embeddedautomation.com/forum